



USER MANUAL

ASP116 EVOLUTION

Lift controller

Hydraulic version



**Edition
10-2022**

CONTENTS

PRESENTATION	4
1.1 SAFETY INSTRUCTIONS.....	5
1.2 MECHANICAL CHARACTERISTICS	5
1.3 ELECTRICAL CHARACTERISTICS	5
1.4 CONTROL PANEL	6
2 SETUP THE LIFT EQUIPMENTS.....	7
2.1 MODIFYING A SETTING	7
2.2 RELOADING FACTORY SETTINGS.....	7
2.3 MYLIFT, APPLICATION FOR SMARTPHONE.....	8
2.4 SETUP MENU	8
2.5 CONTROL PANEL CHARACTERISTICS	9
2.6 EQUIPMENT CHARACTERISTICS.....	10
2.7 TEMPERATURE CONTROL	12
2.8 POWER SUPPLY.....	13
2.9 IDENTIFICATION	13
2.10 HOIST MECHANISM	14
2.11 RE-LEVELLING OPERATION.....	18
2.12 BUILDING	19
2.13 USER OPERATION	21
2.14 FIRE OPERATION	23
2.15 VOICE SYNTHESIS	24
2.15.1 <i>Voice synthesis in car</i>	24
2.15.2 <i>Music in the car</i>	25
2.15.3 <i>Voice synthesis on the car roof</i>	26
2.15.4 <i>Voice synthesis on floors</i>	27
2.16 VISUAL INDICATIONS.....	28
2.16.1 <i>Visual indications in car</i>	28
2.16.2 <i>Visual indications on floors</i>	30
2.17 DOORS.....	32
2.18 CAR POSITIONING SYSTEMS	36
2.18.1 <i>Configuration of K04SP/ K05SP</i>	37
2.19 CAR LOAD CONTROLS	38
2.20 OVERSPEED MONITOR FOR MACHINEROOMLESS LIFTS.	38
2.21 EMERGENCY TELEPHONES	39
2.22 ENERGY SAVINGS	39
3 CONFIGURATION OF ELECTRONIC BOARDS « INPUTS / OUTPUTS ».....	40
3.1 CAR AND FLOORS BUTTONS	40
3.1.1 <i>216SP</i>	40
3.1.2 <i>217SP</i>	40
3.2 CONFIGURATION OF SPECIAL I/O OF 217SP	41
3.3 CONFIGURATION OF FLOOR INDICATION.....	41
3.4 CONFIGURATION I/O SUPERVISION.....	42
3.5 I/O CONFIGURATION OF THE BUS FLOORS (228SP, 137SP).....	44
4 LIFT CONTROLLER MAINTENANCE	45
4.1 MAKE CALLS WITH THE CONTROLLER.....	45
4.2 TECHNICAL ASSISTANCE MENU	45
4.3 DIAGNOSIS MENU	47
4.4 FAULTS LIST	48

4.4.1	Power supply	48
4.4.2	Lift	49
4.4.3	Control panel.....	49
4.4.4	Car boards	51
4.4.5	Floor boards	51
4.4.6	Shaft reader	53
4.4.7	K04SP/K05SP.....	54
4.4.8	Safety chain.....	54
4.4.9	Levelling	56
4.4.10	Movement.....	57
4.4.11	Doors	59
4.4.12	Overspeed	60
4.4.13	Temperature	60
4.4.14	Hydraulic hoist	61
4.4.15	GMV NGV A3 Hoist faults.....	62
4.4.16	BUCHER iVALVE Hoist faults.....	62
5	ELECTRONICS BOARDS	63
5.1	ELECTRONICS BOARD IN MACHINERY	63
5.1.1	Lift controller boards « 216SP »	63
5.1.2	217SP expansion board.....	66
5.1.3	214SP Power supply board.....	67
5.1.4	220SP motor interface board	68
5.1.5	226SP Hydraulic expansion board.....	69
5.1.7	212SP safety chain distribution board.....	70
5.2	ELECTRONIC CARS IN INSPECTION BOX	71
5.2.1	211SP car controller board.....	71
5.2.2	210SP safety chain distribution board	75
5.2.3	222SP power board for door second service	77
5.2.4	223SP extension board for door second service	78
5.2.5	230SP Bluetooth board.....	79
5.3	LANDING ELECTRONICS BOARDS	80
5.3.1	228SP landing board	80
5.3.2	137SP landing board with voice synthesizer	81

Presentation

This manual is the reference document for installation and maintenance of your “**ASP 116 evolution**” control panel. It explains in detail the configuration and diagnostic of your control panel.

This new range of control panels designed by Sprinte introduces the latest technology to meet lifts' new requirements. The “**ASP 116 evolution**” control panel is modular and particularly suited to modernising lifts.

Main functionalities:

- 32 floors
- CANopen LIFT compliant

Power control options:

- Variable frequency control 4 kw to 55 kw (Gear and Gearless)
- One or two speed control
- Speed until 1.6 m/s
- Optimization of energy consumption

Car positioning

- Magnetic reader with magnets on guide rails
- Optic fork (224SP)
- Absolute encoder with notched band (K04SP)
- Absolute reader with encoded stainless steel band./

Operation type:

- Universal travel, Up or Down Collective, Full Collective
- Up to quadruplex control
- Fire EN 81-73
- Inspection and emergency operation
- Key “reserved car”
- Overload detection
- Access codes with the car operating panel
- Two car operating panel

Door controls

- 2 doors
- Manual doors
- Fully automatic doors
- VVF doors (Nudging)
- Door open levelling
- Two doors with passing or selective mode
- Automatic and manual landing doors on the same face

Indicators

- Positions indicators (Dot matrix, LCD, TFT colour)
- Direction and next departure arrows
- Voice announcement of floor

Main advantages:

- Only one flat cable
- MP3 speech synthesizer
- Security chain pre-wired
- Configuration and application software saved on the SDCard
- 2 lines * 20 characters LCD display
- All defaults saved on the SD-CARD
- Time and date of the faults
- Control of Machine room temperature
- Voice assistance for the technical

1.1 Safety instructions

- 1) The control panel must be installed in a dry, clean room and only accessible to authorised staff.
- 2) The room temperature must not exceed 40° and must be greater than 0°
- 3) The lift must be taken out of service if the two-way communication system is not working

1.2 Mechanical characteristics

Cabinet size:

Power Operation	4 to 11Kw	15 to 30Kw	37 to 55Kw
Frequency variation	800 x 600 x 300	1200 x 800 x 400	1600 x 900 x 400
Hydraulic control	800 x 600 x 200	800 x 600 x 200	800 x 600 x 200
Electric 1 and 2 speeds	800 x 600 x 200	800 x 600 x 200	800 x 600 x 200

- The cabinet size can vary according to options
- The control panel weight varies between 25Kg and 100Kg according to power

1.3 Electrical characteristics

The control panels are serial equipped with a protection system against lightning and all the contactors are installed on Silentblobs in order to reduce noise emission outside the control panel


Working voltage	220Vac / 230Vac single phase or three phase, 380Vac / 400Vac three phase
Power consumption	70VA no load
Available voltage	24V full-wave 2A, 55V / 70V full-wave 4A, 110Vac / 1A, 220V "220F" /2A
Safety chain voltage	110VAC
Emergency voltage	Battery 12V / 2,1Ah or 7,1 Ah
Call / Car buttons	Inputs / outputs single wire, earth return, voltage 24V continuous Type of indication (LED or light 24V / 50mA max)



This manual describes the functions of the software. It is possible that older versions of software do not have all the features described. Check the version of the software before you start reading the manual.

1.4 Control panel

The control panel comprises an alphanumeric screen and navigation keypad equipped with five integrated buttons. The control panel screen enables the lift's status to be known at all times. The SDCard contains the lift's configuration and the lift's software to enable restarting under the same conditions if the board is changed.



Contrast adjustment

Press and hold down the “**BACK**” key and press “**▲ +**” to increase contrast or “**▼ -**” to decrease it.

Navigating in the menus

Press the “**ENTER**” key on the keyboard to go into the lift's configuration and diagnostics menu. Then press the “**▲**” or “**▼**” keys to navigate in the main menu. Push the “**ENTER**” key again to go into the desired submenu and the “**BACK**” key to come back out of it.

2 Setup the lift equipments

The “**SETUP**” menu is used to adapt the control panel to your lift. It defines the lift’s system requirements as well as the settings enabling the installation’s performance to be optimised.
All the control panels are delivered preconfigured according to the client’s datas.

The parameters with a start indication (example: « [PARAM]* ») are the default parameters

2.1 Modifying a setting

Modifying a setting is only authorised if the “PROTEC CONFIG” setting is set to “NOT PROTECTED”. If not a message “MODIF NOT AUTH.” will appear.

To modify a setting, select it and press the “ENTER” key, the current value starts flashing. Pressing the “▲” or “▼” keys changes its value. To validate your selection press the “ENTER” key again, the new value is saved and does not flash. To cancel your modification press the “ESC” key.

Takes account of modifications

The modifications are not taking account while the lift is in use.

To save the modifications, press the “**BACK**” key several time to return to the main menu

The following message appears:

SAVE?
YES (+) NO (-)

Press “+” to confirm the modification or “-“ to cancel
If you pressed “+” the message “MODIFIED CONFIG” appears

After 2 seconds, you can switch to the standard indication by pressing “**BACK**” key.

Take account of new settings



Wait until the lift is in an available state, ensure there is no-one remaining inside the car then press the “RESET” key for two to three seconds. The lift restarts after initialisation with the new settings.

2.2 Reloading factory settings

The configuration used by the control panel is saved in the DCF.txt file. Each setting modified by the console is therefore saved in this file. In case of a problem loading the configuration or incorrect operation following a configuration modification, you can go back to the factory settings. This configuration is backed-up in the EDS.txt file.

To go back to the factory settings:

- 1) Press the “▲ +” button and the “▼ -“ button
- 2) Do a reset by keeping the “▲ +” and “▼ -“ buttons pressed down

FACTORY SETTINGS
CONFIRMATION OK>

- 3) Press the “ENTER” key.
- 4) The lift control panel is configured with the factory settings

2.3 MyLift, application for smartphone.

“MyLift” application is a software for android-based devices designed to the lift’s owners and intended to help them customize their lift this application gives access only to all of the user’s settings of the lift (voice synthesizer, music, displays, access codes, date & time, etc...). Changes made with this application are taken instantly in account by the controller, no need to reset it.

This application needs the second 230SP board, to give a separate bluetooth access from the first 230SP.

MyLift is available on
Google PlayStore



Every editable settings with Mylift , are identified throughout this document by the logo of the application:

2.4 SETUP MENU

CONTROL PANEL	Protection of settings modification, selection of display language on the digital console, date and time adjustment
EQUIPMENT	Control panel series type, consulting software version, number of expansion boards
TEMPERATURE	Machinery temperature adjustment detection
POWER SUPPLY	Phase inversion
IDENTIFICATION	Name of client, address of lift, serial number, lift number in multiplex
HOIST	Hoist mechanism : Hydraulic systems, drive systems
LEVELLING	Levelling of the car with the doors opened
BUILDING	Number of levels, car stop level,..
OPERATIONS	type of operation, car light timer, car priority timer, car priority key
FIRE	Configuration of stricken floors, type of fire operation
VOICE SYNTHESIS	Voice synthesis configuration
INDICATORS	Configuration of type of displays landings and car with configuration of display at each level. Type of arrow on landing and in car
DOORS	Type of doors, nudging, timers, CPC, SHOCK, opening/closing button, electro cam, pre-opening.
CAR POSITION	Type of reader, recalibration, close levels, crossed flags
CAR LOAD	Overload ,complete
OVERSPEED	Settings for the overspeed monitor
ALARM	phone alarm configuration
ENERGY SAVINGS	Settings for the energy savings mode of the lift.
BOARDS I/O	Input-output settings for electronic boards of the controller

2.5 Control panel characteristics

SETUP ► CONTROL PANEL

SETUP	Protection of settings modification
	<p>[PROTECTED]* Consulting the configuration. No setting can be modified in this mode</p> <p>[NOT PROTECTED] Consulting and modifying the configuration</p>
LANGUAGE	Choix de la langue d'affichage sur la console de l'armoire
	[FRENCH]* [ENGLISH]
DATE 	Date display
	<p>Date setting :</p> <p>Press « ENTER » and press the arrows to change the day, the month and the year. Press « ENTER » to validate the new date or « ESC » to cancel.</p>
TIME 	Time display
	<p>Time setting :</p> <p>Press « ENTER » and press the arrows to change the hour, the minutes and the second. Press « ENTER » to validate the new time or « ESC » to cancel.</p>
NIGHT START 	Display of start time for night schedule
	<p>The night range is used to reduce the sound volume of the vocal synthesis during the night</p> <p>Adjustment as for TIME setting</p>
NIGHT END 	Display of end time for night schedule
	Adjustment as for TIME setting

2.6 Equipment characteristics

CONFIGURATION ► EQUIPMENT

VERSIONS	Application version and electronic boards version of the equipment
	[y.z]
POWER BOARD	Type of power board connected to the 216SP board
	[NO BOARD], [220SP], [220SP+226SP]
PIT INSPECT. BOX	<p>Presence of an inspection box in the pit. If this box is present on your lift, you can plug it on 137SP board connected on the landing CAN bus, or directly on 216SP main board Be aware that in case of 137SP ,this board is not to be considered in the « LAND. BOARDS NB » (see below in this table). This 137SP board is fixed to ID #27, e.g. DIP1 DIP2 DIP4 and DIP5 set to ON, all others set to OFF</p>
	[NO], [ON CN7/137SP], [ON PE3M/216SP]
PIT INSP.REARM.	<p>Selection of the reset system after exiting pit inspection mode This reset system may be fulfilled :</p> <ul style="list-style-type: none"> • either by ASP116 Evolution (procedure is fully detailed in the installation manual B-DP-13-006 Ann.2-5), • or by an external autonomous device
	[BY ASP116-EVO], [BY EXT.SYSTEM]
PIT INSP.VOLUME	<p>Volume ajustement of pit inspection box. This setting is available only if the pit inspection box is managed by a 137SP board .</p>
	[0..7]
DBD (Door Bypass device)	<p>Presence of Door safety contacts bypass device. This device is required by EN81-20 standard for maintenance of the doors' contacts.</p>
	[NO], [YES]
217SP BOARDS NB	Number of 217SP boards
	<p>[0*..2]</p> 
223SP BOARDS NB	Number of 223SP boards
	[0*..2]
LAND. BOARDS NB	Number of 228SP and 137SP boards on landing CanBus
	<p>[0*..25] The boards are identified by the JT1 selector of the boards. The identification is binary code: DIP 1 = 1 if DIP1 is ON, DIP 2 = 2 if DIP2 is ON, DIP 3 = 4 if DIP3 is ON, DIP 4 = 8 if DIP4 is ON, DIP 5 = 16 if DIP5 is ON, Board = $V_DIP1 + V_DIP2 * 2 + V_DIP3 * 4 + V_DIP4 * 8 + V_DIP5 * 16$</p> <p>Examples :</p> <p>Board 0 : All the DIPs OFF Board 10 : DIPs 2, 4 are ON Board 23 : DIPs 1, 2, 3, 6 are ON</p> <p>The "0 board" is the last on the bus (she has a tank circuit). The previous board is numbered 1 and so on.</p>

230SP BOARDS NB	<p>Number of 230SP boards This board is used for Bluetooth communication and remote alarm LEDs</p> <p>[0*..2]</p>
BLUETOOTH PIN	<p>Access code to the gateway 230SP n°0 This code secures bluetooth access to the lift control panel with EvoPAD application.</p> <p>[XXXX]</p>
<p>CUST.BTOOTH PIN</p> 	<p>Access code to the gateway 230SP n°1 This code secures bluetooth access to the lift control panel with the application dedicated to the final customer (“MyLift” app., ...)</p> <p>[1234] (default value)</p>
MPLEX	<p>Multiplex gateway Using a gateway between the lift control panels to separate the floors CANbus This parameter can't be disabled if there is at least one board connected on the landing bus (landing panel board ,pit inspection board , flexypage..).</p> <p>[OUI] * [NON]</p>

2.7 Temperature control

SETUP ► TEMPERATURE

Chapter 0.4.16 of the standard EN81-20:2014: To ensure the correct functioning of the equipment in the well and machinery space(s), i.e. taking into account the heat dissipated by the equipment, the ambient temperature in the well and the machinery space(s) is assumed to be maintained between +5 °C and +40 °C.

Temperature control in the control panel	
This security prohibiting lift operation if the temperature in the control panel exceeds the maximum tolerances authorised by the electronic components.	
MAX PANEL T°	<p>Maximum temperature in control panel</p> <p>If the temperature exceeds this threshold, the lift makes the passengers exit and goes out of service until the temperature comes back down below the threshold</p> <p>[20..70] °C (70°C by default)</p>
MIN PANEL T°	<p>Minimum temperature in control panel</p> <p>If the temperature goes below this threshold, the lift makes the passengers exit and goes out of service until the temperature goes back up above the threshold</p> <p>[-10..15] °C (0°C by default)</p>
Temperature control in machine room	
Security prohibiting lift operation if the temperature in the machine room exceeds the maximum tolerances authorised by the standard.	
MACHINE ROOM T°	<p>Activation of the temperature controls in the machine room</p> <p>Le control sis done by a 132SP temperature captor that it is connected to the MC2M connector of the 216SP board.</p> <p>[YES]* [NO]</p>
MAX MACHINE T°	<p>Maximum temperature in machine room</p> <p>If the temperature exceeds this threshold, the lift makes the passengers exit and goes out of service until the temperature comes back down below the threshold</p> <p>[20..60] °C (40°C by default)</p>
MIN MACHINE T°	<p>Minimum temperature in machine room</p> <p>If the temperature exceeds this threshold, the lift makes the passengers exit and goes out of service until the temperature comes back down below the threshold</p> <p>[-10..15] °C (0°C by default)</p>
HEATING	<p>Switching on heating if temperature is lower than the threshold</p> <p>Output CN6I-CHAUF / 220SP is activated</p> <p>[-10..18] °C (5°C by default)</p>
VENTILATION	<p>Switching on ventilation if temperature is greater than threshold</p> <p>Output CN6I-VENT / 220SP is activated</p> <p>[22..60] °C (30°C by default)</p>

2.8 Power supply

SETUP ► POWER SUPPLY

PHASE CONTROL	Detection of phase inversion or failure
	[NO DETECTION] [DETECTION]*

2.9 Identification

CONFIGURATION ► IDENTIFICATION

CLIENT	Name of client Name of company
	[16 characters]
REFERENCE	Reference name Lift address where control panel is installed
	[16 characters]
SERIAL NUMBER	Control panel serial number
	[YYMMXXX] YY : Year of manufacture MM : Month of manufacture XXX : Number in the month
SIMPLEX NUMBER	Multiplex lift number
	[1*..4] In multiplex each lift must have a separate number
LIFT MARK	Serial lift number displayed in car
	N° [16 characters]
CE MARK	CE mark displayed in car
	[XXXX]
CONSTRUCT.YEAR	Construction year of the lift This construction year will be displayed next to the CE mark on the load plate of the 236SP1 display.If the year is set to 0, nothing will be displayed.
	[XXXX]

2.10 Hoist mechanism

CONFIGURATION ► HOIST

TYPE HYDRAULIC	Type of hydraulic pack
	[STANDARD] [INVERTER] [BUCHER LRV] [GMV NGV A3] [BUCHER IVALVE]
INSPECTION SPEED	Selection of movement speed during inspection  Inspection speed must not exceed 0.63 m/sec
	[LOW SPEED]* [HIGH SPEED]
UP STARTING	Type of start of the gear for the going up movements.
	[DIRECT] [STAR-DELTA]
STAR-DELT TIMING	Star / Delta timing
	[0..5] seconds (1,5s by default)
TIMING UP VALVE	Timing delay of the up travelling valve actuation, with regard to the line contactor
	[0..5] seconds (0s by default)
SH. DOWN UP VALVE	Shutdown the up valve before or after the line contactor with the « TIMING UP VALVE » temporization
	[BEFORE MOTOR] [AFTER MOTOR] *
A3 VALVE	Drive of the safety valve required by the A3 amendment
	[NO] * [YES]
A3 TEST AUTO	Down and A3 valves automatic test. On the 4th of each month, an automatic test of the valves will be launched at 4 a.m.. A down movement is ran, first only with A3 valve opened, then only with down valve opened. If the car has moved downward in one of both cases, a fault is recorded and the lift is set out of order.
	[OUI] * [NON]
A3V. ON DELAY	Timing delay between the opening of the safety valve and the going down valves
	[0..2] seconds (0s by default)
A3V. OFF DELAY	Timing delay between the closing of the safety valve and the going down valves
	[0..2] seconds (0s by default)
OIL HEAT SWITCH	Temperature control of the oil heat switch of the oil hydraulic unit
	Check the temperature of the oil in the reservoir. If the input captor plugged on CN13I-STH / 220SP is activated, the car stop to the next level and the lift is out of order. [NO] [YES]*
OVERPRESSURE	Overpressure control of the oil hydraulic unit

	<p>If the input CN13I-SPR / 220SP is activated, the lift is immediately in “out of service” mode but the emergency going down operation keeps working.</p> <p>[NO] [YES]*</p>
NO CAR MOVEMENT	<p>Timing to detect a no movement of the car Maximum car movement time without having information from position reader. Once time is passed, the lift is faulty. This security is deactivated in INSPECTION mode and LEVELLING mode</p> <p>[1..20] seconds</p>
MAX ACCELER.	<p>maximum authorized acceleration of the car measured by K04SP/K05SP</p> <p>[0..2,5] m.s2 (2,5 sec by default) « 0 » value disables the function</p>
MAX LS TIMING	<p>Maximum low speed movement lift in normal service</p> <p>[10..90] seconds (20 s by default)</p>
THERMAL PROTECT	<p>Type of thermal protection of the traction machine Use the input CN12I-ST / 220SP</p> <p>[NO PROBE] [RESISTIVE PROBE] [DRY CONTACT]*</p>

Timing sequences for hydraulics hoists and valves


- **Going up in direct or in star/delta mode :**

DIRECT :


DELTA output is driven immediately

START/DELTA :

First **STAR** output is driven during T2 delay, then **DELTA** output is driven simultaneously with upward valves.



- **Going down**




- **Levelling**

Downward, levelling is managed the very same as a normal low speed downward movement..

Upward, levelling is managed the very same as a normal low speed upward movement,

EXCEPT when the hoist has an auxiliary pump motor for levelling. (see §2.11) , it will be driven in Direct mode (output NIV-CN7-0 on 226SP board) instead of the standard pump motor.

Upward levelling with an auxiliary motor :



T1 Upward valve delay (before OR after DELTA)

- **Emergency going down operation**

In case power supply failure, the car going down to the most lower level
 The output “CN6-O SDS / 226 SP” is driven only if the safety chain is closed.

2.11 Re-levelling operation

SETUP ► LEVELLING

LEVELLING	LEVELLING OPERATION Maintaining the car at landing level with doors open. This function is deactivated in call or inspection mode Connector CB10 / 211SP
	[NO] No pickup is done if the car drifts in door area. Only forced closing of doors if the car exits the door area [YES] Movement of the car with doors open in the door area due to activation of security relay to level the car in case of drift. Movement is done at low speed with spring cam.
LEVELLING MOTOR	Selection of the levelling motor The levelling motor can be the main motor or an auxiliary motor.
	[AUXILIARY MOTOR] [MAIN MOTOR]
LEVELLING TIME	Maximum levelling time This is the maximum time to regain level in case of car backstop. If the car has not regained its level within this time, a fault "LEV. TOO LONG" is given.
	[05..30] seconds
LEVELLING CT	Levelling counter A limited number of levellings is authorised on the landing. A fault "LEV REPEATED" is activated if the threshold is exceeded.
	[5..15]
LEVELLING TPO	Holding time of levelling Once the floor is reached, the levelling is still ON until the duration of this delay. This delay creates an hysteresis on the levelling trigger.
	[0..10] seconds (0s by default)

2.12 Building

SETUP ► BUILDING

LEVELS NUMBER	Number of levels served by lift
	[2..32] Adjustable from 2 to 32 level
MAIN LEVEL 	Main level On Collective, the landing buttons below the main level are “up land” and the other landing buttons “down land”. The car goes back to main level in case of fire operation
	[0..31] <i>This setting is reset to zero if it is higher than the numbers of levels.</i>
GAPS LEVELS	Management of gaps levels for bank of lifts (multiplex) . The elevator that going down to the lowest level will have GAPS LEVELS = 0. Other lifts that can not going down to the lowest level indicates the number of levels they cannot serve with this parameter. Example of a duplex: The elevator that has 3 subsoil has GAPS LEVELS = 0 The elevator that has 1 subsoil has GAPS LEVELS = 2 The levels of the landings buttons are configured by referring to the elevator coming down the lowest. Levels of the car buttons are configured as a simplex
	[0..31]
RETURN TO FLOOR 	Return to a dedicated floor after a waiting time
	[NO] [YES]
TIME STOP FLOOR 	Waiting time before the car returns to its stopped floor
	[0..20] minutes
STOPPED FLOOR 	Level of the stopped floor In hydraulic, the stopped floor is obligatory the lowest.
	[0..31]
‘OUT OF USE’ LVL 	Level of the ‘Out of Use’ operation When this operation is activated , the lift will park at this floor.
	[0..31]
OOU.DOORS OPENED	Parking doors opened in ‘Out Of Use’ operation
	[NO] [YES]
CAR BLOCK TIMER	Detection time of a blocked lift Maximum time limit for taking calls into account. If the lift has calls waiting and the time expires, then the lift is put into blocked state. In this state, car sending and landing calls in progress are erased to warn the users that the car will not be coming. In multiplex, is excluded from the bank. If the cause of the blocking disappears and a new call is made, this will be responded to.
	[Disabled, 30sec, 1mn, 1mn30sec, 2mn,.....9mn30sec, 10mn] (2mn default value)

<p>RETRAC TOE-GUARD</p>	<p>Retractable toe-guard It is necessary to indicate the use of a retractable toe-guard as safety is deactivated by a cam on the lowest level (connector DETECT 1m 210SP board). The control panel must check that the cam returns correctly to normal position once the car has exited the area.</p> <p>[NO] [YES]</p>
<p>LVL ACCESS CODE</p> 	<p>Access code with the car buttons to reserve an access to a floor.</p> <p>Levels can be protected by a code entered using the button box cab. Ten levels can be protected and it is possible to choose which side door is secure. The access code is 4 digits.</p> <p>ACCES 1...ACCES 10 DOOR [1..2] LEV [0..31] CODE [XXXX]</p>
<p>LEVEL CODE ACTI.</p> 	<p>Access code Schedule of the protected floors The access codes may be active night and day or only part of the day or by activation of an external input</p> <p>[DAY ONLY] [NIGHT ONLY] [NIGHT AND DAY] [EXTERNAL INPUT]</p>
<p>BUILD.ACC.CODE</p> 	<p>Access code of the building Protection of all the floors by a unique code.</p> <p>[ON/OFF] CODE [XXXX]</p>
<p>BUILD. CODE SCHED</p> 	<p>Access code schedule of the building The access code may be active night and day or only part of the day or by activation of an external input</p> <p>[DAY ONLY] [NIGHT ONLY] [NIGHT AND DAY] [EXTERNAL INPUT]</p>
<p>INTERCOM TPO</p>	<p>Timer to re-enable car call A disabled car call (via input BLOCK CAR) will be re-enabled during this delay once the matching input « UNBLCK CAR » is activated.</p> <p>[0..255] seconds</p>

2.13 User operation

CONFIGURATION ► OPERATIONS

OPERATION	Operation type
DOUBL.CALL ERASE	<p>[UNIVERSAL] [UP OR DOWN] [FULL COLLECTIVE]</p> <p>Erase the up and down floor button Erase the up and down floor button when the car arrives at the level</p> <p>[NO]* [YES]</p>
 <p>REDUCE PARKING</p>	<p>Reduction of the parking temporization If this option is "YES" pressing a button in the cabin shortens the delay of parking and improves the performance of the elevator in buildings with low traffic.</p> <p>[NO]* [YES]</p>
 <p>CAR LIGHT TIME</p>	<p>Car light on time Time during which the car remains lit up when the lift is in an available state</p> <p>[3..60] seconds</p>
 <p>CAR PRIORITY TIME</p>	<p>Car priority timer A user in the car must have a minimum of 2 secs after the doors close to select his destination (5.12.4.2 EN 81-20).</p> <p><u>Operation during timer duration:</u> In collective operation, if no movement direction is assigned, the user in the car has priority on the next destination. In blocking operation, the landing buttons indicate car occupation and the user in the car has priority on the next destination.</p> <p>[0..10] seconds</p>
<p>CAR PRIO KEY</p>	<p>Car priority key This key in the car reserves the lift for car calls, landing calls are suspended. "series 1" PE3M-CCC / 216SP "series 2" CB9-CCC / 211SP</p> <p>[NO] [YES]</p>
<p>FIREMEN PRIO KEY</p>	<p>Priority call for firemen Enables rapid intervention by fireman, brings the car to priority level. Input TR1M-CPO / 216SP</p> <p>[NO] [YES]</p>
<p>FIREMEN LEVEL</p>	<p>FIREMEN LEVEL Car call level in case of firemen priority call</p> <p>[0..31]</p>
<p>INSPECT. EXIT TIME</p>	<p>Inspection exit time Minimum time to return to normal mode after exiting inspection mode. This time is a safety measure, it enables leaving the technician time to exit the car roof before the lift goes back into normal mode</p> <p>[10..120] seconds (10 seconds par default)</p>
<p>INS. END LIMIT</p>	<p>Inspection movement beyond the end decelerator Select here whether you want to forbid the inspection movement beyond the end decelerators (top and bottom)</p> <p>[MOVEMENT ALLOW.] [MOVEMENT FORBID.]</p>

HWAY.ACC.DETECT**Hoistway access detection**

The hoistway access detection sets the lift out of order (“HOISTWAY ACCESS” fault, see 4.4.11), in the case a landing door has been detected opened for longer than 8 seconds (thanks to the landing doors safety locking contact), out of a normal car parking in user mode. The presence of a technician is mandatory to set back the lift in user mode.

This detection only occurs in user mode

Caution : this detection can't operate properly with a lift compliant to EN81-20 standard , as in that case the landing doors are always unlocked when the lift is idle in user mode.

[NO.] [YES]

2.14 Fire operation

CONFIGURATION ► FIRE

Configure here how the lift is managed in case of fire

TYPE	Fire operation type Operation 81-73 brings the car back to the secure floor, evacuate the passengers, then the lift is set out of order Operation according to U36/G36 only disables stops on stricken floors, the lift is still in service for users
	[DEACTIVATED] [EN81-73 STANDARD] [U36/G36 STANDARD]
DETECTION	Type of fire detection Choose here how the fire operation is launched “STRICKEN FLOORS” inputs are set on 217SP board “MANUAL CALL” is on TR1M-CPO 216SP board
	[STRICKEN FLOORS] [MANUAL CALL]
SECURE FLOOR	Fire security floor Security floor where the car goes when the fire operation is launched.
	[0..31]
SUBSTITU. FLOOR	Substitution floor If the “fire security floor” is stricken, the car goes to this substitute floor
	[0..31]
DOOR OPEN	Parking door open Choose the parking mode once the car is at the fire security floor
	[NO] [YES]

2.15 Voice synthesis

CONFIGURATION ► VOICE SYNTHESIS

2.15.1 Voice synthesis in car

CONFIGURATION ► VOICE SYNTHESIS ► CAR

VOICE	Voice synthesis activation
	[NO] [YES]*
DAY VOLUME 	Volume adjustment for day time
	[0..7] (3 by default)
NIGHT VOLUME 	Volume adjustment for night time
	[0..7] (3 by default)
DOOR 1 ANNOUNCE and DOOR 2 ANNOUNCE 	Configuration of messages on arrival at landing for each door
	No message or "Basement 6" to "Basement". "Ground floor", "Floor 0", "Floor 0 0 " "1st floor" to "35th floor " "Shops", "Exit floor", "Exit", "Garage", "Main floor", "Parking", "Lobby" "Cafeteria", "Hotel" . "Floor 1 / 2" to "Floor 34 / 35" "SPECIAL1" to "SPECIAL16". <i>You can create your own floor messages, choose "SPECIAL1" to "SPECIAL16". and rename your MP3 files into "SPECIAL1.mp3" to "SPECIAL2.mp3" then copy it in the folder "SPECIAUX " of the SDcard of 211SP board (car roof)</i>
START ANNOUNCE	Choice of setting off of message announcement on arrival at landing
	[SLOWING]* [ARRIVAL]
OPENING DOORS 	Announcement of the doors opening
	[NO ANNOUNCE]* [OPENING] [OPENING DOORS]
CLOSING DOORS 	Announcement of the doors closing
	[NO ANNOUNCE]* [CLOSING] [DOORS CLOSING]
DEPART ANNOUNCE 	Sound announcement of next car departure If the option is selected, there will be one tone for going up and two tones for going down in accordance with the 8170 standard or a voice message saying UP or DOWN.
	[NO ANNOUNCE] [VOICE MESSAGE] [GONG 1T/2T n°1] [GONG 1T/2T n°2] [GONG 1T/2T n°3]
CAR BUTTON BEEP	A beep is generate when a car button is actived
	[NO] [YES]*
MUSIC ENTER >>	Submenu for music broadcast in car
	See chapter 2.15.2 below

CAR ALERT	Vocal request to stay away from the door. In case the door is blocked more than 15s after the parking timer (because of light barrier or Reopen button), then on each new hall call request, a vocal announcement is launched in car requesting to stay away from the door.
	[NO] [YES]

2.15.2 Music in the car

CONFIGURATION ► VOICE SYNTHESIS ► MUSIC.

 ACTIVATION CODE	Unlocking of the function For broadcast licensing reasons, this code will be provided if you want to use the function. A broadcast license fee will also be provided. This broadcast license is valid for only one lift. All musical settings below will then become accessible..
	[00000..99999] 5 digits code.
 STYLE	Choice of musical style Set the musical style you want to have in the car. Choosing « NO » will stop the function. By choosing a predefined style , you will broadcast the music provided by Sprinte. <i>The musical files provided by Sprinte are under license (©) . This broadcast license is available for only one and only lift.</i> By choosing « CUSTOM », you will broadcast the musical files located in the folder « User » of the SDcard of the 211SP car roof board. <i>If you want to broadcast your own musical files, be sure that you have the legal rights to do it.</i>
	[NO] [CUSTOM] [CLASSICAL ©] [ELECTRO ©] [LOUNGE ©] [JAZZ ©] [POP ©]
 RANDOM PLAY	Random play of musical files
	[NO] [YES]
 DAY VOLUME	Volume adjustment for day time
	[0..7] (3 by default)
 NIGHT VOLUME	Volume adjustment for night time
	[0..7] (3 by default)

Music is broadcasted only in user's operation of the Lift. It starts at the very first user's call and stops only when the car becomes available again, when car's light is switched off. The music restarts on the next user's call, continuing the musical files that was interrupted.

The floors' announcements and users' vocal messages are a priority on music.

The music stops immediately when exiting user's operation (Inspection, Emergency operation, Out of order, ...).

2.15.3 Voice synthesis on the car roof

CONFIGURATION ► VOICE SYNTHESIS ► CAR ROOF

VOICE	Voice synthesis activation
	[NO] [YES]*
DAY VOLUME	Volume adjustment for day time
	[0..7] (3 by default)
NIGHT VOLUME	Volume adjustment for night time
	[0..7] (3 by default)
OPENING DOORS	Announcement of the doors opening
	[NO ANNOUNCE]* [OPENING] [OPENING DOORS]
CLOSING DOORS	Announcement of the doors closing
	[NO ANNOUNCE]* [CLOSING] [DOORS CLOSING]
DEPART ANNOUNCE	Sound announcement of next car departure If the option is selected, there will be one tone for going up and two tones for going down in accordance with the 8170 standard or a voice message saying UP or DOWN.
	[NO ANNOUNCE] [VOICE MESSAGE] [GONG 1T/2T n°1] [GONG 1T/2T n°2] [GONG 1T/2T n°3]
ARRIVAL GONG	Generate a gong at the arrival of the car at the destination
	[NO GONG]* [ARRIVAL] [SLOWING]

2.15.4 Voice synthesis on floors

CONFIGURATION ► VOICE SYNTHESIS ► ON FLOORS

(Only if « LAND. BOARDS >0)

VOICE	Voice synthesis activation
	[NO] [YES]*
SYNTH. CHOICE ENTER >>	Choice of the synthesis type at each levels
	[LANDING LOUDSP] [ROOF LOUDSPEAKER]*
DAY VOLUME ENTER >>	Volume adjustment for day time at each level
	[0..7] (3 by default)
NIGHT VOLUME ENTER >>	Volume adjustment for night time at each level
	[0..7] (3 by default)
OPENING DOORS	Announcement of the doors opening
	[NO ANNOUNCE]* [OPENING] [OPENING DOORS]
CLOSING DOORS	Announcement of the doors closing
	[NO ANNOUNCE]* [CLOSING] [DOORS CLOSING]
DEPART ANNOUNCE	Sound announcement of next car departure If the option is selected, there will be one tone for going up and two tones for going down in accordance with the 8170 standard or a voice message saying UP or DOWN.
	[NO ANNOUNCE] [VOICE MESSAGE] [GONG 1T/2T n°1] [GONG 1T/2T n°2] [GONG 1T/2T n°3]
ARRIVAL GONG	Generate a gong at the arrival of the car at the destination
	[NO GONG]* [ARRIVAL] [SLOWING]

2.16 Visual indications

CONFIGURATION ► DISPLAYS

2.16.1 Visual indications in car

CONFIGURATION ► INDICATION ► CAR

DISPLAY	Display type [NO DISPLAY] [61SP/63SP] [122SP/123SP] [LCD WECO] [232SP COLOR] [235SP BLUE] [VEGA] [236SP COLOR] [FLEXPAGE]
FLEXPAGE NB	Number of flexyPage in car. (only if DISPLAY = FLEXPAGE) As the flexyPage display is mastered by the controller on the CANopen bus, it shall be informed how many are connected on. [0..2]
LOAD PLATE (only with 236SP)	Informations to display on the load plate of 236SP [NON] : No load plate on the display. [1 : NOM LOAD] : Nominal load of the car and number of persons. (Set both values in menu CONFIGURATION -> CAR LOAD) [2 : 1+SERIAL NB.] : NOM LOAD + Serial number of the lift (Set the value in menu CONFIGURATION -> IDENTIFICATION) [3 : 2+ CE MARKING] : NOM LOAD + SERIAL NB+ CE marking with symbol (Set the value in menu CONFIGURATION -> IDENTIFICATION)
CUSTOMER LOGO  (only with 236SP)	Display of the customer's logo on the 236SP [YES] [NO]
ORIENTATION (only with 232SP)	Select the 232SP display orientation [LANDSCAPE] [VERTICAL]
1 BKGND/FLOOR (only with 236SP) 	The background of 236SP is associated with each level. On level 0 , file 001.BMP is displayed ; on level 1 , file 002.BMP; on level 1 , file 003.BMP etc.... The parameter « BACKGROUND PIC.» (see below) won't be available anymore. [YES] [NO]
BACKGROUND PIC. (232SP and 236SP) 	Select background display <ul style="list-style-type: none"> • 232SP : [BLUE] [RED] • 236SP : [SLIDESHOW], [FILE 001.BMP]... [FILE 028.BMP] Choose a specific image file for the background or a slideshow of the 28 image files available
SLIDESHOW TIM.  (only with 236SP)	Time for the display of an image in slideshow mode [1min], [3min], [5min], [10min], [15min], [30min], [1h], [3h], [5h], [10h], [24h]
TIME AND DATE  (232SP & 236SP)	Displays the time and date [YES] [NO]
LAST VISIT (only with 236SP)	Displays the date of the last maintenance visit. This date has to be updated in ASSISTANCE-> VISITE DONE. [YES] [NO]

NEXT VISIT (only with 236SP)	Sélection de la périodicité de la prochaine visite en semaines The date of the next visit is calculated by adding this value here , to the date of last visit.		
	[NON], [1 WEEK]... [6 WEEKS]		
DEVICE MESSAGE (only with 236SP)	Display of emergency device presence message		
	[YES] [NO]		
EMCY. LIGHT (232SP and 236SP)	The display act as the emergency light in case of car light failure		
	[YES] [NO]		
FLOORS INDICATION  ENTER >>	Choice of indication to display at each floors Display possibilities depend on the display type		
	See appendix for available display depending on the display present in the equipment		
ARROWS	Arrows type: Output arrows direction of movement board 211SP CB1-FD , CB1-FM Output arrows next departure board 211SP CB9-FDP, CB9-FMP		
	[NO ARROWS] [61SP/63SP] [122SP/123SP] [DIRECT]		
BUTTON FLASHING 	Flashing car buttons		
	[YES] [NO]*		

2.16.2 Visual indications on floors

CONFIGURATION ► INDICATION ► ON FLOORS

<p>CONFIG.FLOORS</p> <p style="text-align: right;">ENTER >></p>	<p>Sub-menu for configuration floor by floor (see table on next page) <i>(Only if there are landing boards with your equipment installation AND no flexyPage are used on floors)</i></p> <ul style="list-style-type: none"> • Display type • Floor indication • Specific options of the display <p>[ON FLOOR 00]... [ON FLOOR 31]</p>
<p>216SP DISPLAY</p>	<p>Display connected on 216SP Board Output AFT-TR3M on 216SP board , for 61SP/122SP/ LCD WECO displays type. Output CN1-M on 216SP board for 235SP/232SP/236SP displays type.</p> <p>[NO DISPLAY] [61SP/63SP] [122SP/123SP] [LCD WECO] [232SP COLOR] [235SP BLUE] [VEGA] [236SP COLOR]</p>
<p>FLOOR/DISPLAY</p>  <p style="text-align: right;">ENTER >></p>	<p>Choice of indication to display at each floors Display possibilities depend on the display type</p> <p>See appendix for available display depending on the display present in the equipment</p>
<p>FLEXPAGE NB</p>	<p>Number of flexyPage on floors. As the flexyPage display is mastered by the controller on the CANopen bus, it shall be informed how many are connected on.</p> <p>[0..2]</p>
<p>TIME AND DATE</p>  <p>(232SP and 236SP)</p>	<p>Displays the time and date</p> <p>[YES] [NO]</p>
<p>CUSTOM LOGO 236</p>  <p>(only with 236SP)</p>	<p>Display of the customer's logo on the 236SP</p> <p>[YES] [NO]</p>
<p>236 BCKGND PIC.</p>  <p>(only with 236SP)</p>	<p>Select background display for 236SP</p> <p>[FILE 001.BMP]... [FILE 028.BMP] Choose a specific image file for the background .</p>
<p>232 BCKGND PIC.</p>  <p>(only with 232SP)</p>	<p>Select background display for 232SP</p> <p>[BLUE] [RED]</p>
<p>ORIENTATION</p> <p>(only with 232SP)</p>	<p>Select the 232SP display orientation</p> <p>[LANDSCAPE] [VERTICAL]</p>
<p>ARROWS</p>	<p>Arrow type Outputs TR3M FD, FM / 216SP for traditional wiring</p> <p>[NO ARROWS] [61SP/63SP] [122SP/124SP] [DIRECT]</p>
<p>ARROWS INDIC</p>	<p>Arrow indications The arrows have to be arrows for moving in blocking</p> <p>[MOVEMENT] [NEXT DEPARTURE]</p>
<p>BUTTON FLASHING</p> 	<p>Buttons flashing during movement</p> <p>[NO] [YES]*</p>

ARRIVAL GONG 	Gong signal of arrival of car at landings Gong outputs are controlled on the 217SP expansion board by the output “GONG ARRIV NIVXX” where XX is the arrival level
	[NO GONG] [STOPPED] [SLOWING]

CONFIGURATION ► INDICATION ► ON FLOORS ► CONFIG.FLOOR ► ON FLOOR 00 ... 31

This menu is available only if there are landing boards with your equipment AND no flexyPage are used on floors

For each floor :

LANDING DISPLAY	Display type
	[NO DISPLAY] [61SP/63SP] [122SP/123SP] [LCD WECO] [232SP COLOR] [235SP BLUE] [236SP COLOR]
FLOOR/DISPLAY 	Choice of indication to display at this floor. Display possibilities depend on the display type
	See appendix for available display depending on the display present in the equipment
BACKGROUND PIC  (only with 236SP)	Select background display for 236SP
	[FILE 001.BMP]... [FILE 028.BMP] Choose a specific image file for the background .
ORIENTATION (only with 23SP)	Select the 232SP display orientation for this floor
	[LANDSCAPE] [VERTICAL]

2.17 Doors

CONFIGURATION ► DOORS

NB DOORS	Number of doors
	[1..2]
DOOR 1	Door 1 configuration
DOOR 2	Door 2 configuration
FLOORS	Configuration of doors types on different landings
	<p>If option one door: [DOOR 1] [BLOCKED]</p>
	<p>If option one door with two different type (automatic, manual) [TYPE DOOR 1] [TYPE DOOR 2] [BLOCKED]</p> <p>If option two doors: [DOOR 1] [DOOR 2] [2 DOORS PASSING] [2 DOORS SELECTIVE] [BLOCKED]</p>

Doors Configuration

CONFIGURATION ► DOORS ► DOORS 1
OR CONFIGURATION ► DOORS ► DOORS 2

MANUFACTURER	Door manufacturer reference
	[STANDARD] [SCHINDLER QSK8-9]
	Doors SCHINDLER QSK8-9 - Automatic Doors with limit switch closure and opening. - Maintained close command during car movement. - Shunt not controlled during the stop level.
2 DOORS TYPES	One door face and two doors types It is possible to manage doors and automatic doors on the same service door
	[NO] [YES]
DOORS TYPE	Selection of the door type
	[NO DOOR] : no control of door opening or closing [AUTOMATIC] : automatic door in car and landing [MANUAL LANDING] : automatic door in car and manual landing [FLUSH SHAFT] : no car door, with control of light barrier.
DOOR # SWITCH (only for MANUAL LANDING door type)	Safety contact wiring for car door Depending on the wiring diagram, this contact may be plug on Car Shunt, or Lock . Check on which input of CB20 plug of 210SP is wired the safety door contact.
	[ON LCOK] Choose this if door is wired on VERC1-CB20 / 210SP [ON CAR SHUNT] Choose this if door is wired on SHC1-CB20 /210SP
PRE-OPENING	Pre opening of the door in door unlock area The opening of the door will start in door unlock are, just before the car completely stops on the destination floor.
	[NO] [YES]
PRE-OPENING TRIG	Trigger for pre-opening of the door Select here at which distance from the level, the pre-opening has to start. With a 224SP reader, the choice is done by position flag events. With a K04SP reader, the choice is done in centimeters.
	224SP : [DOOR-AREA ENTRY] [STOP-FLAG ENTRY] [STOP-FLAG EXIT] K04SP / K05SP : [5..30] cm
MAINTAINED CLOSE	Forced closing during car movement Maintaining doors closed command while car is moving
	[NO] [YES]
NUDGING	Closing doors in NUDGING mode Door closing command at low speed and with high torque if the door is not shutting. A voice signal is broadcast to warn of danger. Door control by nudging: NUD1-CB8 / 211SP
	[NO] [YES]
CLOSING TIMER	Maximum door opening time

	The opening command is stopped by “closing limit switch” or end of timer.
	[2..45] seconds
OPENING TIMER	Maximum door opening time The opening command is stopped by “closing limit switch” or end of timer.
	[2..45] seconds
PARKING TIMER	Car parking time with door open Time during which the car stays with door open to let users exit and enter in car <u>Shorten time:</u> Automatic door: Press car button “Door closing” manual door : Closing landing door
	[2..20] seconds
TMR ON REOPENING	Car stopping time when reopening In case of reopening of the door because of a shock or a light barrier event, the door will be kept opened during this following value :
	[1..10] seconds
TP DEBOUNCING SH	Temporization of shunt debouncing on floor doors This temporization is launched once the floor door is closed. With manual landing doors, this temporization delayed the car door closing With automatic landing doors, this temporization delayed the reopening of the doors caused the de shunt debouncing.
	[0..3] seconds
PHOTO CELL	Door closing protection by cell Causes reopening if the cell is cut and the car is in a door area and closing with nudging if the car is outside of door area. This protection is not active if the door is closed.
	DOOR 1 : [NO] [CB8 / 211SP-24Vdc] [CB19 / 210SP-220Vac] DOOR 2 : [NO] [CB36 / 223SP-24Vdc] [CB16 / 210SP-220Vac]
DOOR SHOCK	Door closing protection for shock Complete reopening of doors if a shock is detected during closing. Doors remain open if closing was not possible after several attempts and while input is active. Connector « CHC1-CB8 / 211SP »
	[NO] [YES]
CLOSE BUTTON	Accelerated closing of doors button Connector « FAC1-CB1 / 211SP »
	[NO] [YES]
REOPEN BUTTON	Door reopening button Connector « OAC1-CB1 / 211SP »
	[NO] [YES]
CLOSING SWITCH	Doors with limit switch closing
	[NO] [YES]

OPENING SWITCH	Doors with limit switch opening
	[NO] [YES]
THERMAL PROTECT	Presence of thermal protection for door motor The presence of this protection will enable the management of the door's motor overheat monitoring Probe for Door 1 : input CB4-I1 / 211SP Probe for Door 2 : input CB4-I2 / 211SP
	[NO] [YES]
RETIRING CAM	Management of the retiring cam device to unlocking the landing doors. The cam is automatically released if the car is stopped. Connector door 1 « CAM 1-CN11-I / 220SP » Connector door 2 « CAM 2-CN9-I / 220SP »
	[NO CAM] [STANDARD CAM]
CAM RELEASE	The cam can be released either before or after opening doors. In case of cam released before door opening, " TP CAM RELEASE " time gives a delay between cam release and door opening. In case of cam released after door opening, " TP CAM RELEASE " gives a delay between door opening and cam release.
	[BEFORE OPENING] [AFTER OPENING]
TP CAM RELEASE	Temporisation of cam release for landing doors unlock.
	[1..30] tenth of seconds.

2.18 Car positioning systems

CONFIGURATION ► CAR POSITION

READER	Type of reader
	[224SP/211SP] [K04SP] [K05SP] [SENSORS/211SP]

Settings for flags' reader systems (224SP, SENSORS)

CONFIGURATION	Flags configuration STANDARD : flags are automatically set according the to kind of deceleration flags for each level (see below DECELERATION FLAG) SCREEN BY SCREEN : flags have to be completely set separately .Choose this flag configuration , only if you can't use the configuration STANDARD
	[STANDARD.] [SCREEN BY SCREEN]
DECELERATION FLAG	Adjustment of deceleration flags for each level Depending on the distance between landings and the car speed, the deceleration flags need to be configured
	[NORMAL] [CROSS-OVER] [CLOSE LEVELS]
SCREEN SETUP	Adjustment of each deceleration flag. Every single flag has to be configure separately : choose first the kind of flag (Top Decelerator TD , level stop LVL or Bottom decelerator BD), then choose the associated level ([xx])
	[LVL] [TD] [BD] ... [xx]
INTER FLOOR TPO	High speed inter floor movement timer This timer is used to set a high speed setting time between two levels if the car keeps in low speed for a too long time due to the deceleration flags position
	[0..10] seconds
CALIBR RISE TIME	Rise time for the cab before reader calibration phase This delay serves to raise the car enough to reach its high speed before detecting the low speed limit switch
	[0..9] seconds
RESET SKIDDING	RESET SKIDDING In some case with a 224SP reader, if where there is a big distance between floors or if the lift is a very low speed lift, the SLIDDING security can be set if the travel time without seeing a flag is superior to 20 sec. To avoid this, it is necessary to activate this option and to plug a magnetic finger to the input DTC of the 211SP board.
	[NO] [YES]

2.18.1 Configuration of K04SP/ K05SP

SLOWDOWN FLAG	Relative position of the slowdown flag
	[0..300] centimeters
UP STOP FLAG	Position of up travel stop flag
	[10..100] centimeters
DOWN STOP FLAG	Position of down travel stop flag
	[10..100] centimeters
FLOORS POSITION	Absolute position of the floors (PALIER 0 to PALIER 31)
	[0..150] meters
DOWN SLOWDOWN	Relative position of the “down slowdown flag” for near floors movement
	[0..300] centimeters
UP SLOWDOWN	Relative position of the “up slowdown flag” for near floors movement
	[0..300] centimeters

2.19 Car load controls


CONFIGURATION ► CAR LOAD

LIFT CAPACITY	Car nominal load in kilograms This value is displayed on the 236SP if chosen in the display settings (see §2.16.1)
	[0...9999] kg
NB. OF PEOPLE	Car nominal load in number of persons This value is displayed on the 236SP if chosen in the display settings (see §2.16.1)
	[0...99]
OVERLOAD	Car overload detection
	[NO DETECTION] [PE2M-SU / 216SP] [CB7-SU / 211SP]
NON STOP FULL	Non stop full detection
	[NO DETECTION] [PE2M-NSC / 216SP] [CB7-NSC / 211SP]

2.20 Overspeed monitor for machineroomless lifts.

CONFIGURATION ► OVERSPEED

The overspeed monitor watches the speed of the car in every operation mode of the Lift.(user, out of power, maintenance). The speed and direction of the car are displayed as soon as the lift switches in 'OUT OF POWER' mode. This menu is displayed only in case of K04SP or K05SP shaft reader (see §2.18.1).



The lift will be set 'Out of Order' whether

- The car speed exceeds the nominal speed in user mode.
- The car speed exceeds the rescue speed in out of power mode.
- The car speed exceeds the maintenance speed in inspection mode.
- No datas is received from the K04SP/K05SP reader while trying to move.

DETECTION	Overspeed monitor
	[NO] [YES]
RATED SPEED	Nominal speed of the car The lift will be set out of order if the car speed exceeds 15% this speed
	[0.01..2] m/s
EMCY SPEED	Maximum speed of the car in out of power mode. This speed shall be set during the installation of the lift, with tests in out of power mode. The overspeed indication 'OS' will be displayed if this speed is 10% exceeded.
	[0.01..2] m/s

2.21 Emergency telephones

CONFIGURATION ► EMERGENCY PHONE

ALARM FILTER	Filtering alarm call in car Output DIS-CB6 / 211SP
	[NO] [YES]

2.22 Energy savings

CONFIGURATION ► ENERGY SAVINGS

STOP&GO MODE	<p>This mode reduces the consumption of the inverter while the Lift is stopped in user mode.</p> <p>Before enabling this function, be sure your cabinet is equipped with KSG contactor. This mode is activated once the lift is stopped for 20 minutes. Then, "STOP & GO" is displayed on Controller. The « STOP&GO » can be tested in the menu ASSISTANCE ► INVERTER FREQ ► STOP&GO ACTIVATE</p>
	[NO] [YES]
 DISPLAY STANDBY	<p>This mode reduces the consumption of 232SP, 235SP displays on floors and in the car. The backlight of the screens is switched off.</p>
	[NO] [YES]
 STANDBY TIMER	<p>Timer value before activating the DISPLAY STANDBY</p>
	[0...20] min

3 Configuration of electronic boards « inputs / outputs »

I / O boards are fully programmable electronic

CONFIGURATION ► I/O BOARDS

211SP BOARD	Inputs / outputs of 211SP
216SP BOARD	Inputs / outputs of 216SP
217SP 0 BOARD	Inputs / outputs of 217SP (extension 1)
217SP 1 BOARD	Inputs / outputs of 217SP extension 2)
220SP BOARD	Inputs / outputs of 220SP
223SP 0 BOARD	Inputs / outputs of 223SP (extension 1)
223SP 1 BOARD	Inputs / outputs of 223SP (extension 2)
230SP BOARD	Inputs / outputs of 230SP (Bluetooth)
LANDING BUS BOARDS	Inputs / outputs of 137SP and 228SP landing bus

3.1 Car and floors buttons

3.1.1 216SP

CONFIGURATION ► I/O BOARDS ► 216SP

PE5M, TR2M	Lift buttons connectors
[TYPE] [LEVEL]	[NO CONNECTED] [CAR DOOR1] [CAR DOOR2] [UP FLOOR DOOR1] [UP FLOOR DOOR2]] [DOWN FLOOR DOOR1] [DOWN FLOOR DOOR2]

3.1.2 217SP

CONFIGURATION ► I/O BOARDS ► 217SP

To assign the connectors to lift calls the following parameter must be configured:

[CONNECTOR] = [LIFT BUTTONS]

ES1-X, ES2-X ES3-X, ES4-X	
[TYPE] [LEVEL]	[NO CONNECTED] [CAR DOOR1] [CAR DOOR2] [UP FLOOR DOOR1] [UP FLOOR DOOR2]] [DOWN FLOOR DOOR1] [DOWN FLOOR DOOR2]

3.2 Configuration of special I/O of 217SP

CONFIGURATION ► I/O BOARDS ► 217SP

To assign the connectors to special functions, the following parameter must be configured:

[CONNECTOR] = [SPECIAL I/O]

ES1-X, ES2-X ES3-X, ES4-X	[TYPE] [LEVEL]
[NOT CONNECTED]	The I/O isn't used
[CAR AT LVL] [LVL##]	The output indicates that the car is stopped at the level and the car doors are opened.
[STRICK.LVL] [LVL##]	Input for stricken level (input NC) : note, the fire operation must be active (see §2.14)
[ARRIV.GONG] [LVL##]	pulse output of 9 seconds to command the arrival gong (68SP type)
[FLOOR LIGH] [LVL##]	pulse output of 0.5 seconds to command the floor lighting at the car arrival
[CAR POSIT.] [LVL##]	The output indicates the car position at the slowdown
[>LVL ACCES CODE]	Activate the levels access codes.
[>BUILD.ACC.COD]	Activate the building access code.
[>H CALLS DISABLE]	Deactivation of the floor calls. This option permit to condemn a lift
[>SET OUT OF USE]	This input sets the lift out of use when activated. All calls are cleared and the car goes to the 'out of use' level (cf 2.12 "BUILDING"). Once arrived the lift is set out of use (the fireman operation keeps priority).
[<LIFT OUT OF USE]	This output indicates the status of 'OUT OF USE' operation.
[BLOCK CAR] [NIVxx]	This input when activated inhibits the matching car call.
[UNBLCK CAR] [NIVxx]	This input ,when activated, enables the matching previously disabled car call, during the timer set in INTERCOM TPO (see §2.12)
[ENB. COD NO] [NIVxx]	This normally opened input, when activated, enables the matching access code in car. This input is effective only if parameter "LEVEL CODE ACTI. " is set to "EXTERNAL INPUT" (see §2.12)
[ENB. COD NC] [NIVxx]	This normally closed input, when activated, enables the matching access code in car. This input is effective only if parameter "LEVEL CODE ACTI. " is set to "EXTERNAL INPUT" (see §2.12)

3.3 Configuration of floor indication

CONFIGURATION ► I/O BOARDS ► 217SP

To assign the connectors to **LEVEL INDICATOR**, the following parameter must be configured:

[CONNECTOR] = [LEVEL INDICATOR]

The level is in gray code

Level	code	output ES1-X8- ES1-X1ES1
0	0x0	0000 0000
1	0x1	0000 0001
2	0x3	0000 0011

3	0x4	0000 0010
4	0x6	0000 0110
5	0x7	0000 0111
6	0x5	0000 0101
7	0x6	0000 0100
../..		

3.4 Configuration I/O supervision

CONFIGURATION ► I/O BOARDS ► 217SP

To assign the connectors to I/O REMOTE, the following parameter must be configured:

[CONNECTOR] = [I/O REMOTE]

ES1-X, ES2-X ES3-X, ES4-X	Entry options
[>AUTO MOVEMENT]	Generates car's travels at all levels
[>GOTO TOP FLOOR]	Generate a call to the highest floor
[>GO LOWEST FLOOR]	Generate a call to the lowest floor
[>OPEN DOOR 1]	Open door 1
[>OPEN DOOR 2]	Open door 2
[>REMOTE RESET]	Reset the lift controller

ES1-X, ES2-X ES3-X, ES4-X	Output options
Powers state	
[<CAR LIGHT FAULT]	Indicates a fault on the Car light
[<POWER FAILURE]	Main power supply is off
[<PHASE ERROR]	Fault on one phase of the main power supply
Safety chain state	
[<S.CHAIN CLOSED]	The safety chain is closed (VERR)
[<LOCKING FAULT]	Fault with the locking contact of the landing doors
[<CAR S.CHAIN]	Car door is closed (SHC)
[<FLOORS S.CHAIN]	Floors doors are closed (SHP)
[<PASSIVE S.CHAIN]	Passive safety (STOP, LIMITER, SAFETY GEAR)
[<ALIM. S.CHAIN]	Safety chain is powered
Elevator operating mode	
[<OVERLOAD]	Lift is in overload
[<OUT OF USE]	Lift out of service
[<EMERGENCY OPERA]	Lift in emergency operation

[<FIREMEN]	Lift in firemen operation
[<INSPECTION]	Lift in maintenance operation
[<LIFT IN USE]	Lift in user's mode operation
Car movement	
[<CAR AT LEVEL]	Car stopped at a level
[<MOVING]	Car is moving
[<CAR MOVING UP]	Car is moving up
[<CAR MOVING DOWN]	Car is moving down
Doors	
[<DOOR 1 OPENING]	Request indication of « door 1 » opening
[<DOOR 2 OPENING]	Request indication of « door 2 » opening
[<DOOR 1 CLOSING]	Request indication of « door 1 » closing
[<DOOR 2 CLOSING]	Request indication of « door 2 » closing
[<OLS DOOR 1]	Open door 1 limit switch
[<OLS DOOR 2]	Open door 2 limit switch
[<CLS DOOR 1]	Close door 1 limit switch
[<CLS DOOR 2]	Close door 2 limit switch
[<SHOCK DOOR 1]	Shock on door 1
[<SHOCK DOOR 2]	Shock on door 2
[<CELL DOOR 1]	Cell on door 1
[<CELL DOOR 2]	Cell on door 2
[<REOPEN. BUTTONS]	Door 1 or 2 Reopening button is pressed
[<ALARM BUTTON]	User's alarm button in car is pressed
[<CALL PENDING]	An user's request is pending or in progress.

3.5 I/O configuration of the bus floors (228SP, 137SP)

CONFIGURATION ► ► I/O BOARDS ► FLOORS BOARDS

Configuration of the landing buttons. The boards are identified from 0 to 24.

LEVEL	Level assigned to the landing board
	[0..32]
DOOR	Door assigned to the landing board
	[DOOR 1] [DOOR 2]
LIFT 1 2 3 4	Lift affected to the landing board
	ASC 1 2 3 4 [0 0 1 0] (the board is associate to lift n°3)
CN4, CN5-E1, CN7	Landing buttons
	[NOT CONNECTED] [CAR CALL] [UP FLOOR BUTTON] [DN FLOOR BUTTON] [FIREMAN KEY NC] [FIREMAN KEY NO] [SET OUT OF USE] [H.CALLS DISABLE]
CN5-S2, CN5-S3	Special output at the floor
	[NOT CONNECTED] [MOVING UP][MOVING DOWN] [CAR AT LVL IND] [OUT OF USE]

4 Lift controller maintenance

4.1 Make calls with the controller

Press the “▲ +” to send the car to the highest level or “▼ -” to send it to the lowest level. Then confirm the request by pressing the “ENTER” key.

If you wish to move the car to other levels, simply press the “▲ +” key then “▼ -”

4.2 Technical assistance menu

AUTO MOVEMENT	<p>Automatic movement of car This mode is used to do a lift endurance test. It causes sending the car up and down. Sending the car and landing calls by users are always taken into account and have priority over this operation. Caution, this test may cause motor overheating, ensure that the “Motor temp probe” security is operating.</p>
	[NON] [BETWEEN FLOORS] [RANDOM]
DOOR BLOCKING	<p>Prevention of door opening This option carries out automatic movement without opening the doors</p>
	[NO] [YES]
H. CALLS DISABLED	<p>Disable the floors calls buttons during auto movement test</p>
	[NO] [YES]
BLACK BOX	<p>Lift black box Records all information on lift operation activity in a log file</p>
	[NO] [YES]
VTA	<p>Voice technical assistance This option guides the technician by voice when troubleshooting the system</p>
	[NO] [YES]
DISPLAY TEST	<p>Test for correct operation of displays and speech synthesis Carries out a test cycling through the configured displays</p>
	[NO] [YES]
LIMIT SWIT. TEST	<p>Test the shaft limit switch</p> <p>With this test, the car goes to the selected limit switch in low speed This test is performed only when the car is in user mode, Car must be stopped at the lowest level for the low limit switch test Car must be stopped at the highest level for the high limit switch test</p>
	[NON] [LOW LIMIT SWITCH] [HIGH LIMIT SWITCH]
A3 VALVE TEST	<p>A3 safety valve test This test helps to check the correct functionality of A3 valve. It executes a down-movement for 5s , first with A3 valve off-driven and Slowdown valve on-driven. then with A3 valve on-driven and Slowdown valve off-driven. In both cases, If the valves are in good condition, the car should not move.</p>
	[NO] [YES] See the installation manual for the full detailed procedure of the test.

SKIDDING TEST	<p>Skidding fault detection test. This test moves the car in slow speed, ignoring all information's datas from the saht reader. Once the « NO CAR MOVEMENT » timer (see §2.10) has elapsed, the « SKIDDING » fault must have been detected and recorded.</p> <p>[NO] [YES] See installation manual for full description of this test.</p>
LEVELLING TEST	<p>Levelling functionality test This test moves the car with the doors opened, then you can check the automatic releveling of the lift.</p> <p>[NO] [YES] See installation manual for full description of this test.</p>
REPROG. BOARDS	<p>Launch a software upgrade for a distant board Use this function, if there is a « VERS. BOARD » in the controller's fault list, in case you have replaced a distant board (211SP or 230SP in car, or 228SP, 137SP on floors), in order to upgrade the software according to the one of the controller.</p>
POSITION DISPLAY	<p>Displays absolute reader (K04SP/K05SP) information - speed, altitude, precision stopping, direction of travel</p> <p>[NO] [YES]</p>
VISIT DONE	<p>Updates the date of the last maintenance visit Selecting "YES", the date of the last maintenance visit is updated to the current date of the controller. This date will be displayed on the 236SP color display in car if you have selected the option (see §2.16.1).</p> <p>[NO] [YES]</p>
LAST VISIT	<p>Displays the date of the last maintenance visit</p>

4.3 Diagnosis menu

Indication of errors encountered during lift operation. All anomalies encountered during lift operation are recorded and can be consulted in this menu.

FAULT LIST	FAULT LIST Recording of last twenty faults. Each fault is numbered from 1 to 20 from the oldest to the most recent. On each fault press Enter to have more detailed informations
MULTIPLEX BUS	STATUS OF MULTIPLEX BUS CONNECTIONS Gives indications on operational status of multiplex bus. Each lift has a status: 0 => not connected 1 => connected
SERIAL LINKS	STATUS OF CONTROL PANEL'S SERIAL LINKS Gives indications on operational status of communications CN1 (RS485), CN2 (RS485), CN5 (CANBUS), CN6 (CANBUS), CN7 (CANBUS), CN11 (217SP expansion board)
TEMPERATURE	TEMPERATURES DETECTED BY 132 PK SENSORS Depending on number of sensors, this menu displays current temperature of 216SP SENSOR and machine room sensor
STATISTICS	STATISTICS Gives information on lift use Counter of number of starts Travels counter per floor Date of last power failure Rope wear counter
SAFETY CHAIN	State of Safety contacts inputs
I/O 220SP BOARD	State of 220SP board inputs outputs
I/O 211SP BOARD	State of 211SP board inputs outputs
I/O 223SP 0/1 BOARD	State of 223SP board inputs outputs
VOLTAGES	Display of low voltage on the 211SP

4.4 Faults list

Pressing the “ENTER” key gives the number of faults recorded than pressing on the “▲” or “▼” keys scrolls through the list of recorded faults.

Pressing and holding down the “ENTER” key on a fault gives the day, time and floor where the fault appeared.

To delete the faults list, scroll through the faults list until you get to “DELETE FAULTS?” Then press the “ENTER” key

Type of faults:

(OOM) OUT OF ORDER MAINTENED: The lift is out of order, only intervention by a technician can put it back in service. You have to delete the faults in the diagnosis menu to get the Lift back in user mode.

(OO) OUT OF ORDER: The lift is out of order, when the fault disappears the lift goes back in service.

ALARM: The control panel indicates a minor fault but the lift remains in service.

4.4.1 Power supply

POWER SUPPLY		
OO	POWER FAILURE	Power failure or no V24
The lift goes into emergency mode, all commands in progress are stopped. <ul style="list-style-type: none"> - Check the input voltage - Check fuses on “PFS1” fuse and position of “PFS1” micro-circuit breaker - Check T380, T0, V24 fuses on 104SP power supply board 		
OO	PHASE ERROR	Absence or reversal of phases (EDF mains supply)
Detection of this fault can be deactivated by the configuration menu Reverse phases L1, L2, L3 and check voltage between each phase on control panel's input terminal block.		
ALARM	CAR LIGHTING	The car lighting is out of order
The car is illuminated by emergency lighting. Check car lighting power supply. The car goes to the destination floor and goes out of service <ul style="list-style-type: none"> - The 211SP board LCP LED and the 212SP board D2 LED must be ON, check the 212SP board's LCP fuse 		

4.4.2 Lift

LIFT		
ALARM	STRICKEN FLOOR	One or more levels are stricken
- Check inputs on 217SP board		
ALARM	FIRE CALL	The lift is called by the firemen
Check manual call input CPO-216SP and stricken levels		

4.4.3 Control panel

CONTROL PANEL		
OO	217SP N°XX OO	217SP extension board is out of service
The control panel no longer manages to interact with 217SP expansion boards.		
<ul style="list-style-type: none"> - Check that the configuration switch is in the correct position - Check the connector CN1/ 217SP then do a reset. - If the problem persists, change the 217SP then 216SP board. 		
OO	223SP N°XX OO	223SP extension board is out of service
The control panel no longer manages to interact with 223SP extension boards.		
Check the connector CN3 /223SP, do a reset, change the 223SP then 211SP board.		
XX = 00 for board with SW1 1 =OFF		
XX = 01 for board with SW1 1 =ON		
OO	MACHINE BUS OFF	Frequency inverter bus is cut off
Serial communication with the frequency inverter is cut off.		
<ul style="list-style-type: none"> - Check CN6M / 216SP - Check the CANopen connector of the frequency inverter - Change 216SP board 		
OO	MULTIPL BUS OFF	Multiplex bus is cut off
Serial communication between the machinery board (216SP board) and the other 216SP boards of other battery control panels is cut off		
<ul style="list-style-type: none"> - Check CN8M / 216SP - Check the presence of resistors at the each extremities of the multiplex bus 		
OOM	WINCH BOARD	Communication fault with winch board 220SP
Serial communication between the machinery board 216SP and the winch board 220SP		
- Check CN4M/216SP		
ALARM	FAULTY SD	Files error on SD card
The controller is not able to write files on the SD card due to deficient sectors found.		
The Lift is still working but it's not possible to modify any settings.		
- Change the SD card and contact our AfterSales department in order to recover your files.		
ALARM	SD WRITING	Files error on SD card

The writing of parameters file failed and is not possible anymore.
The Lift is still working but it's not possible to modify any settings.

- Change the SD card and contact our AfterSales department in order to recover your files.

ALARM	FILE OPEN	Parameter file is unreadable
--------------	------------------	-------------------------------------

The controller's parameter file is unreadable or not present on the SD card.
The Lift is still working but it's not possible to modify any settings.

- Change the SD card and contact our AfterSales department in order to recover your files.

ALARM	CONFIG VERSION	Invalid parametre file
--------------	-----------------------	-------------------------------

The controller's parameter file is not compatible with the software version of the controller.
The Lift is still working but it's not possible to modify any settings.

- Change the SD card and contact our AfterSales department in order to recover your files.

OO	CONFIG SDCARSD	Configuration fault
-----------	-----------------------	----------------------------

No valid configuration exists in the controller (nor in memory neither on SDcard). The controller and so the lift can't operate.

- Change the SD card and contact our AfterSales department in order to recover your files.

ALARM	DIAL LIFT. N°XX	Error on CAN multiplex communication
--------------	------------------------	---

The "CAN" communication between the control panels is not operating correctly. The lifts can operate in multiplex.

- Check the CN7M / 216SP and CN8M / 216SP connectors
- Check the that the cable is not near from a power cable

ALARM	MULTIPLEX NUMB	Error of the lift identification on the multiplex bus
--------------	-----------------------	--

At least, 2 lifts have the same lift number

- Modify the number of one lift in the menu IDENTIFICATION

ALARM	CLOCK OFF	The 216SP board's clock is not working
--------------	------------------	--

- Change the 216SP board

ALARM	CLOCK SETTING	The clock is not set.
--------------	----------------------	-----------------------

- Please set time and date in the CONFIGURATION -> CONTROL PANEL

ALARM	MISSING SD 211	La SD card of 211SP board (car roof) is missing.
--------------	-----------------------	--

Therefore vocal messages can't be broadcasted anymore.

- Check if the SD card is present and properly inserted.
- Otehrwise, replace the SDcard

ALARM	211 INIT AUDIO	The audio system of 211SP had to be reinitialized
--------------	-----------------------	---

An audio file could not be broadcast, the problem has been detected and corrected by the 211SP card.
This defect is just informative, everything works as before.

ALARM	SECU SOFTW XX	Software security
--------------	----------------------	--------------------------

This fault is a software security.

- Make a reset and inform our After Sales department.

OO	DBD SWITCHED ON	Door Bypass Device was engaged
-----------	------------------------	---------------------------------------

This device is engaged and therefore , the lift can't operate in normal user mode. Only emergency recall operation and inspection mode are allowed)

4.4.4 Car boards

CAR BUS		
OO	COMM. BOARD 211	Communication error with 211SP board
CANbus communication between the car (211SP board) and the machinery (216SP board) is not operating correctly <ul style="list-style-type: none"> - Check the CN5M / 216SP connector and PE1 / 211SP connector - Check cabling in inspection box. Ensure that the high voltage wires do not go over the top of the 211SP board. - In case of door control by 380V, ensure that the 69SP filters are connected 		
OO	211SP REPROGR.	Error on car roof 211SP board programming
<ul style="list-style-type: none"> - Make a new software update of the control panel - Change the 211SP board 		
OO	211SP VERSION	The software version of the 211SP car is wrong
<ul style="list-style-type: none"> - Make a new software update of the control panel 		
ALARM	COMM 230 SP #XX	Communication error with 230SP board
CANbus communication between the car (230SP board) and the machinery (216SP board) is not operating correctly <ul style="list-style-type: none"> - Check the CN5M / 216SP connector and CN1 / 230SP connector 		
ALARM	230 #XX REPROGR.	Error on 230SP Bluetooth board programming
<ul style="list-style-type: none"> - Make a new software update of the control panel - Change the 230SP board 		
ALARM	230SP #00 VERS.	The software version of the 230SP car is bad
<ul style="list-style-type: none"> - Make a new software update of the control panel 		
ALARM	230SP #XX SAME ID	The both 230SP boards have the same Canbus ID
<ul style="list-style-type: none"> - Make a new software update of the control panel 		
ALARM	COMM. FLEXPAGE #X	Communication error with flexyPage (#1 or #2)
<ul style="list-style-type: none"> - Check the CAN bus connection of the flexyPage 		

4.4.5 Floor boards

FLOOR BOARDS		
ALARM	COM BOARD N°XX	Communication error with a floor board
The 216SP board meet some communication error with a floor board <ul style="list-style-type: none"> - Verify the connectors - Change the 228SP or 137SP board 		
ALARM	WRONG VERS. N°XX	Wrong software version of the floor board
The software version of the floor board is not compatible with the control panel software.		

- Make a new software update of the control panel

ALARM REPROG BOARD N°XX Software upgrade error of a floor board

The software upgrade of floor board N°XX didn't ended properly

- Try once again a new software upgrade
- Change the board

ALARM SAME ID N°XX Two floor boards have the same identifier

- Modify the switches position of the floor boards

ALARM COMM. FLEXPAGE #X Communication error with flexyPage (#1 or #2)

- Check the CAN bus connection of the flexyPage

ALARM COMM. PIT INSPEC. Communication error with the pit inspection board 137SP

The 216SP board met some communication error with a the pit inspection board 137SP

- Verify the connectors
- Change the 137SP board

ALARM VERS. PIT INSPEC. Wrong software version of the pit inspection board 137SP

The software version of the pit inspection board 137SP is not compatible with the control panel software.

- Try once again a new software upgrade

ALARM PROG. PIT INSPEC. Software upgrade error of the pit inspection board 137SP

The software upgrade of the pit inspection board 137SP didn't ended properly

- Try once again a new software upgrade
- Change the board

ALARM ID. PIT INSPEC. Two boards have the identifier of the pit inspection board 137SP

- Check the DIPs of the floor boards.
- Only one shall have ID number #27. (ID number dedicated to the pit inspection board 137SP).

4.4.6 Shaft reader

READER		
ALARM	CELL C	Cell detection error door area
- Check the reader's "cell C"		
ALARM	FLAG READER	Flag reader error
This fault makes a car repositioning for reader calibration.		
<ul style="list-style-type: none"> - Check the placement of the counting flags - Check the reader position - Check flag position with sequences imposed by the configuration (Crosse-over, close levels) 		
OO	DTC INPUT	The reader 224SP is out of service
<ul style="list-style-type: none"> - Check the configuration matches the reader in place. - Check connection of DTC inputs, C, A, B on CB3-211SP connector (a disconnected wire on one of the inputs causes a DTC error). - Check operation of 224SP reader 		
ALARM	READER ERROR	Reader internal error
- Change the reader		
OOM	RECALIBRATION	Reader recalibration error
Check flags, sensor installation and state of rockers or ILS of top and bottom decelerators.		
OOM	RECALI CELL XX	Magnetic reader error
Check flags, sensor installation and state of rockers or ILS of top and bottom decelerators.		
XX = A : Check cell A is operating correctly		
XX = B : Check cell B is operating correctly		
XX = AB : Check cells A and B are operating correctly		
ALARM	LOSS DOOR AREA	Loss of door area while car is stopped
The doors are closed automatically if the "DOOR AREA" signal is lost during opening or when stopped		
<ul style="list-style-type: none"> - Check the cell C for a magnetic selection, check the distance between the sensor and the magnet - Check the position of the door area screen for an optical selection. - Check the operation of 224SP optical reader. 		
ALARM	OUT OF DOOR AREA	Door opening request outside area
The car wanted to open its doors without the door area being detected.		
- Check the reader, check the door area, check the safety chain		
OO	DOOR AREA ON	The door area is always active.
The door area information is always active on the controller, whatever the car position .		
<ul style="list-style-type: none"> - Check cell C for magnetic reader. - Check the operation of 224SP optical reader. 		

4.4.7 K04SP/K05SP

K04SP/K05SP		
OO	DIAL COM	The com can't be established with the reader
	<ul style="list-style-type: none"> - Check CB11 / 211SP - Check that the cable is not near a power cable 	
OO	ERR. POSITION	Floors position error
	<ul style="list-style-type: none"> - Restart a shaft learning procedure 	
OO	OUT OF WORK AREA	The reader is out its work area
	<ul style="list-style-type: none"> - Remake a reader calibration at each floors 	
OO	BATTERY	The battery is out of services (K04SP only)
	<ul style="list-style-type: none"> - Replace the K04SP 	
OO	TEMPERATURE	La temperature is too high (K04SP only)
	<ul style="list-style-type: none"> - Check the reader temperature 	

4.4.8 Safety chain

SAFETY CHAIN		
OO	CHAIN POWER	Safety chain power supply fault
	<ul style="list-style-type: none"> - Check the safety chain power supply - Check the fuse CHS on the 214SP board. The CHS LED must be ON 	
OO	EMERGENCY STOP	Lift in emergency stop
	<ul style="list-style-type: none"> - Check the primary safety chain : MACHINERY STOP, STOP RECESS, PARACHUTE, SPEED GOVERNOR, TENSION PULLEY 	
ALARM	SHORT CIRCUIT	The chain may be short circuited
	<p>On door opening, the control panel has not detected the disappearance of SHUNT or LOCKING.</p> <ul style="list-style-type: none"> - Check that the doors open when they are commanded - Check opening of the shunt in automatic door and locking in manual door during opening - Check the door opening time 	
OOM	END LIMIT SWITCH	Lift at end limit
	<ul style="list-style-type: none"> - Check the distance of DHCS contact hydraulically - Check the distance of FCH and FCB contacts electrically 	
OO	SH TOE GARD	Shunt toe gard
	<p>The retractable toe-gard is permanently shunted by the cam « detect 1m » that is at the bottom level.</p> <ul style="list-style-type: none"> - Check the switch.of the cam « detect 1m » 	
ALARM	SHUNT	SHUNT detection problem

During door closing, the shunt has not been detected after several attempts.

- Check cabling and correct operation of SHUNT
- Check the door closing time covers the actual time for door closing
- Check if CLS does not appear too soon before the SHUNT or if it is not simply disconnected

ALARM	LOCKING	Door locking problem
--------------	----------------	-----------------------------

The doors are not locked after several attempts

- Check correct operation of locking

ALARM	MOV. LOCKING	Breaking LOCKING while moving
--------------	---------------------	--------------------------------------

- Check that the locks' wheels are not hooked by the cam or the door clip during movement

4.4.9 Levelling

The levelling and releveling faults are detected and managed in compliance with chapter 5.6.7 of EN81-20:2014 standard.

LEVELLING		
OO	SAFETY RELAY ON	The safety relay is active even though the control panel is not in "levelling operation"
<p>The VISO contactor's state is continually controlled to avoid any safety risk</p> <ul style="list-style-type: none"> - Check the contactor, change the power board 220SP 		
ALARM	VISO OFF	The VISO contactor is not active even though the levelling order is present
<p>The contactor's state is continually controlled to avoid any safety risk</p> <ul style="list-style-type: none"> - Check the contactor, change the power board 220SP 		
OO	LEV. TOO LONG	The "LEVELLING TIME" time limit has passed
<p>The car has not succeeded in reaching the level within the time limit, in case of backstop, the car goes to its security level</p> <ul style="list-style-type: none"> - Check the security relay is engaged in ISO area - Check the reader, check the electric plant, increase the "LEVELLING TIME" time limit 		
OO	LEV REPEATED	Levelling counter at the max value
<p>The number of car levelling has been exceeded during the 2 minutes In case of backstop, the car goes back to its security level. Only erasing these faults puts the car in service again.</p> <ul style="list-style-type: none"> - Check reader, check the hydraulic circuit 		
OOM	SAFE.REL.CUTOFF	The car went out of the door area while levelling or releveling
<p>The car went out of door area with doors opened, while levelling (preopening of the door) or releveling.</p> <ul style="list-style-type: none"> - Check the position of the magnet for the door area - Check your braking system 		
OOM	ELECTRIC DRIFT	The lift is blocked in backstop "NF82-212"
<p>The car has backstop upwards doors closed for grip winch or downwards for coupled winch Or car has backstop "doors open" and "out of ISO area" before the LEVELLING function can bring car to level.</p> <ul style="list-style-type: none"> - Check brake function, check reader and erase flag from stop area if necessary <p>This fault keeps lift out of order even in case of mains power cut. The memorised faults must be erased for the lift to go back into service again.</p>		

4.4.10 Movement

MOVEMENT		
OO	CONTACTOR STICK	Check if motor control contactors are sticking when a move request
<p>The power contactors are not stuck when requesting movement. The equipment remains out of order during the “BLOCKED CAR TIME” then comes into service again.</p> <ul style="list-style-type: none"> - Check power contactors' control loop - Check the input CC-CN14I / 220SP 		
ALARM	CONTACTOR CHECK	Check if contactors are released before a start
<p>The power contactors are stick before a move request</p> <ul style="list-style-type: none"> - Check air gap between contactors, clean them - Verify the input CC-CN14I / 220SP 		
ALARM	CONTACTR UNSTICK	Check if contactors are released after a travel
<p>The power contactors aren't unstuck after a car travel</p> <ul style="list-style-type: none"> - Check air gap between contactors, clean them - Verify the input CC-CN14I / 220SP 		
ALARM	SLIDING	Car sliding
<p>Car sliding out of the door area causes re-levelling of car</p> <ul style="list-style-type: none"> - Check the brake, valves, cable grip 		
ALARM	ACCELERATION	A sudden acceleration has been detected while moving (K04SP only)
<p>During a car movement command, the controller checks that acceleration doesn't exceed the threshold set (see §2.10). This control of acceleration is intended to detect a breaking of the K04SP belt.</p> <ul style="list-style-type: none"> - Adjust the value the MAX ACCELER. parameter (see §2.10). 		
OOM	SKIDDING DISTANC	The distance travelled during 10s is too short. (K04SP & K05SP readers only)
<p>During a car movement command, the distance travelled during 10s by the car is only about few centimeters.</p> <ul style="list-style-type: none"> - Check the brake, valves, cable grip, motor power supply, inverter... 		
OOM	SKIDDING	The car has not moved on a command from control panel
<p>This fault is detected if the controller doesn't receive any information from the reader during the time set (see §2.10)</p> <ul style="list-style-type: none"> - Check the shaft reader. Brake, motor power supply, variator etc.... - Adjust the “NO CAR MOVEMENT” parameter (see §2.10) 		
ALARM	STOP PRECISION	Stop precision
<p>The car doesn't stop at the level with a good precision. The reader encroachment on second stop screen on arrival at level. Check spacing between stop flag , speed variator's deceleration slopes, distance between slowing down and stop flags</p>		
OO	BOT DECELERATOR	The bottom decelerator switch isn't detected
<ul style="list-style-type: none"> - Check operation of bistable ILS or switches, check ILS or bistable rocker is active until stop on level. <i>This fault is detected only in normal mode.</i> 		
OO	TOP DECELERATOR	The top decelerator switch isn't detected

- Check operation of bistable ILS or switches, check ILS or bistable rocker is active until stop on level.
This fault is detected only in normal mode.

OO	DECELERATORS	The TOP and BOTTOM decelerators are both active
-----------	---------------------	--

- Check operation of bistable ILS or switches
- Check connection of CB2 / 211SP
This fault is detected only in normal mode.

ALARM	MOV. DIRECTION	Control order different from car's movement direction
--------------	-----------------------	--

The direction commands from control panel do not match the reader's movement direction.
If the car is moving in the correct direction, check that spacing between screens is sufficient
This fault causes a recalibration of the reader

- Check sensor installation, reverse motor phases

OO	THERMAL PROBE	Motor overheating
-----------	----------------------	--------------------------

If the motor thermal probe fault appears when car is stopped, the lift is immediately out of order until fault disappears. If the fault is detected during a movement, the car stops at the next landing and remains out of order until the fault disappears.

- Check motor ventilation, motor thermal probe

OO	CC THERMAL PROBE	Fault motor thermal probe sensor
-----------	-------------------------	---

Check motor's thermal probe connected on connector ST-CN12 / 220SP

ALARM	EXIT FROM COURSE	The lift has gone beyond limits of its normal course
--------------	-------------------------	---

The fault causes a recalibration of the reader

- Check programming of level number, check slowing down distance

ALARM	MAX LS TIMER	Maximum movement time at low speed elapsed
--------------	---------------------	---

Check low speed time in the configuration, check bottom level slowing down distance

4.4.11 Doors

DOOR		
XX = S1 : service door 1 XX = S2 : service door 2		
ALARM	CELL XX	Cell protection
The door has not managed to close due to CELL protection. <ul style="list-style-type: none"> - Check correct operation of cell. Door 1 Connectors : CPC1-CB8 /211SP or CPC1-CB19 /210SP. Door 2 Connectors : CPC2-CB36 /223SP or CPC2-CB16 /210SP. 		
ALARM	SHOCK XX	Shock protection
The door has not managed to close due to shock protection. <ul style="list-style-type: none"> - Check shock contact. Connector CHC1-CB8 /211SP (door 1) or CHC2-CB36 /223SP (door 2) 		
ALARM	CLOSING LS XX	No detection of door service closing limit switch
The closing limit switch has not been detected when closing the door <ul style="list-style-type: none"> - Check correct operation of CLS. Connector FCF1-CB8 /211SP (door 1) or FCF2-CB36 /223SP (door 2) - Adjust door closing time - If your door does not have a CLS, indicate this in the door configuration 		
ALARM	OPENING LS XX	No detection of door service opening limit switch
The opening limit switch has not been detected when opening the door <ul style="list-style-type: none"> - Check correct operation of OLS. Connector FCO1-CB8 /211SP (door 1) or FCO2-CB36 /223SP (door 2) - Adjust door opening time - If your door does not have an OLS, indicate this in the door configuration 		
OO	THERMAL PROBE XX	Door's Motor overheating
If the motor thermal probe fault appears when car is stopped, the lift is immediately out of order until fault disappears. If the fault is detected during a movement, the car stops at the next landing and remains out of order until the fault disappears. <ul style="list-style-type: none"> - Check motor ventilation, motor thermal probe 		
ALARM	SR OFF/OPENING	Problem with the safety relay during pre-opening of the doors
The safety relay didn't close for the doors pre-opening request <ul style="list-style-type: none"> - Check the right location of the door zone magnet - Check the trigger level of pre opening operation in the menu. 		
ALARM	OVRSPD/OPENING	Overspeed detected during pre-opening of the doors
The car's speed exceeded 0,8 m/s at the beginning of doors pre-opening operationa(cf 5-12-1-4c EN81-20) <ul style="list-style-type: none"> - Check the deceleration distance in the menu 		
OOM	HOISTWAY ACCESS	An abnormal access in the hoistway has been detected
A landing door has been detected opened for more than 8 seconds ,out of a normal car parking .		

4.4.12 Overspeed

OVERSPEED		
OOM	USER OPERATION	Overspeed in user operation
<p>The car speed exceeded the value allowed in user operation</p> <ul style="list-style-type: none"> - Check your parameters in the OVERSPEED menu - Check the inverter parameters 		
OOM	INSP OPERATION	Overspeed in inspection operation
<p>The car speed exceeded the value allowed in inspection operation</p> <ul style="list-style-type: none"> - Check your parameters in the OVERSPEED menu - Check the inverter parameters 		
OOM	EMCY OPERATION	Overspeed in emergency operation
<p>The car speed exceeded the value allowed in emergency operation</p> <ul style="list-style-type: none"> - Check your parameters in the OVERSPEED menu 		

4.4.13 Temperature

TEMPERATURE		
OO	PANEL T° > MAX T° ou PANEL T° < MIN T°	Exceeding operating temperature in control panel
<p>The 216SP board is equipped with an internal temperature sensor. The control panel is put out of order if the temperature exceeds the temperature authorised in the configuration menu</p> <ul style="list-style-type: none"> - Check the temperature indicated by the sensor menu: "DIAGNOSTIC -> TEMPERATURE -> 216SP SENSOR" - Check temperature threshold of control panel "CONFIGURATION ->EQUIPMENT->216SP MAX T" 		
OO	MACH T° > MAX T° ou MACH T° < MIN T°	Exceeding operating temperature in machinery
<p>132PK external temperature sensors may be connected on MC2-M connector of 216SP board</p> <ul style="list-style-type: none"> - Check the temperature indicated by the sensor in the menu: "DIAGNOSTIC -> TEMPERATURE -> EXT SENSOR XX", XX equal to 1 to 3 depending on number of sensors connected - Check temperature threshold in the configuration "CONFIGURATION ->EQUIPMENT-> MAX MACHINE TEMP" 		
OO	132PK PROBE OO	Temperature probes are not responding
<ul style="list-style-type: none"> - Check the 132PK probes connection on MC2-M connector of 216SP - Check that the configuration matches the number of probes connected 		
OO	216SP PROBE OO	The 216SP board temperature probe does not respond
<ul style="list-style-type: none"> - Change the 216SP board 		

4.4.14 Hydraulic hoist

HYDRAULIC		
OO	DOWN VALVES OFF	Check the down travel valve during car movement
<p>The contactor «down travel valve » hasn't been set on a control panel order. The lift goes in "out of service mode" during all "CAR BLOCKED" timing and goes back in service after.</p> <ul style="list-style-type: none"> - Check the contactor - Change the 226SP board 		
ALARM	DOWN VALVES ON	Check the down travel valve during car stop
<p>The contactor «down travel valve » hasn't been released on a car stop</p> <ul style="list-style-type: none"> - Check the contactor - Change the 226SP board 		
OO	OIL PRESSURE	The oil's pressure is too high
<p>If the oil pressure fault appears when car is stopped, the lift is immediately out of order until fault disappears.</p>		
ALARM	SAFETY CH RESCUE	Check the safety chain in rescue mode
<p>The safety chain is open, the rescue down travel isn't possible</p> <ul style="list-style-type: none"> - Check the safety chain. - Change the 226SP board 		
OO	OIL TOO HEAT	The oil's temperature is too high
<p>If the thermal probe fault appears when car is stopped, the lift is immediately out of order until fault disappears. If the fault is detected during a movement, the car stops at the next landing and remains out of order until the fault disappears.</p> <ul style="list-style-type: none"> - Check the temperature of the oil in the reservoir - Check the probe connected to STH -CN13I / 220SP input 		
OOM	A3 VALVE FAILURE	Detected only during A3 automatic test
<p>During automatic test of A3 valve, the car has moved downward, while driving only the standard downward valve. A3 valve may be damaged .</p>		
OOM	DOWN VALVE FAIL.	Detected only during A3 automatic test.
<p>During automatic test of A3 valve, the car has moved downward, while driving only the A3 valve. The standard downward valve. may be damaged ..</p>		

4.4.15 GMV NGV A3 Hoist faults

GMV NGV A3		
OOM	READY NGV A3 OFF	Ready signal error on stop
Lift stopped.		
OOM	RUN NGV A3 OFF	Run signal error while moving..
While moving.		
OOM	READY NGV A3 ON	Ready signal error while moving..
While moving.the car is moved to the closest floor.		
OOM	RUN NGV A3 ON	Run signal error on stop..
Lift stopped.		


4.4.16 BUCHER iVALVE Hoist faults

BUCHER IVALVE		
OOM	SMA IVALVE STOP	SMA signal error on stop
A l'arrêt.		
OOM	SMA IVALVE MOV.	SMA Signal error while moving
While moving.		

5 Electronics boards

5.1 Electronics board in machinery

5.1.1 Lift controller boards « 216SP »




CN4-M
Connector connecting 216SP controller board to power board 220SP
CN3-M
Connector connecting 216SP controller board to 214SP power supply board
CN11-M
Connector connecting 216SP controller board to 217SP expansion boards

outputs « < » ; inputs NO « > » inputs NC « > / »

PE1-M		AR1-M	
< FM	(not used)	< GND	ground
< FD	(not used)	< GND	ground
< AF	(not used)	> STH	Oil heat switch
< DFT	Out of service	> MR	Emergency operation switch
PE2-M		MC2-M	
> / FCF1	(not used)	> TH	Machinery heat switch
> / FCO1	(not used)	< GND	ground
> / CHC1	(not used)	< masse	screening
> / CPC1	(not used)	MC1-M	
> / FAC 1	(not used)	> 1	(not used)
< GO	GONG	< 2	(not used)
> SU	Overload	< 5	(not used)
> / NSC	No full stop	< 8	(not used)
PE3-M		CN2-M RS485	
> MI	Inspection up	< 1	Data + (A)
> INS	Inspection switch	< 2	Data – (B)
> DI	Inspection down	< 3	GND
> CCC	(not used)	< 4	GND
PE4-M		CN1-M RS485	
> DTC	(not used)	< 1	Data + (A)
> C	(not used)	< 2	Data – (B)
> B	(not used)	< 3	GND
> A	(not used)	< 4	GND
PE5-M		CN5-M	
>C1 à C8	Car and floor buttons	< 1	24 V
PE6-M		< 2	ground
< V24	24 V DC	< 3	24 V
< V12	12 V DC	< 4	ground
< V9	9 V DC	< 5	CANH
< GND	ground	< 6	CANL
TR1-M		CN6-M	
< GND	ground	< 1	24 V
> /RB	(not used)	< 2	GND
> /RH	(not used)	< 3	24 V commanded
> /CPO	Fire man key	< 4	ground
TR2-M		< 5	CANH
> P1 à P8	Car and floor buttons	< 6	CANL
TR3-M		CN7-M et CN8-M	
< GND	ground	< 1	24 V
< AF	Landing display	< 2	GND
< V9	(not used)	< 3	24 V
< V12	12 V DC	< 4	ground
< PN	ground	< 5	(not used)
< V24	24 V DC	< 6	(not used)
< FM	Up arrow	< 7	CANH
< FD	Up arrow	< 8	CANL

LED	STATUS	INFORMATION
V24C	ON	24V commanded
VCC	ON	216SP board powered
DFT	ON	Indicates that the device is not working the LED flashes if boot is faulty
CABINE		
MACHINE		
MULTIPLEX		
FCF1	ON	(not used)
FCO1	ON	(not used)
CHC1	ON	(not used)
CPC1	ON	(not used)
FAC1	ON	(not used)
SU	ON	110% of maximum authorised car load reached.
NSC	ON	80% of maximum authorised car load reached.
INS	ON	(not used)
CCC	ON	(not used)
DTC	BLINK	(not used)
C	OFF	(not used)
B	OFF	(not used)
A	OFF	(not used)
C1 à C8	ON	Sending taken into account.
RB	ON	(not used)
RH	ON	(not used)
CPO	ON	Fireman's key activated.
P1 à P8	ON	Call taken into account.
STH	ON	(not used)
MR	ON	Control panel in emergency mode
OUV1	ON	Door 1 opening command activated.
FER1	ON	Door 1 closing command activated.

5.1.2 217SP expansion board




outputs « < » ; inputs NO « > » inputs NC « > / »

CN1	CN2
Connector connecting the 217SP expansion board to the 216SP board	Connector connecting the 217SP expansion board no. 2 to the 217SP expansion board no. 1
CN3	
Not used	
ES1-X, ES2-X, ES3-X, ES4-X	
X1 à X32	Expansion board inputs / outputs
X25	BUZZER output forced closing of doors
X26	Service 1 nudging output

LED	STATUS	INFORMATION
1 à 32	OFF	Expansion board inputs / outputs activated


5.1.3 214SP Power supply board



CN3-A	→ CN3-M / 216SP
V24	24 V dc
V12	12 V dc
GND	ground
PHI	Detection of reversal or missing phase
CN4-A	→ CN2-I / 220SP, CN2-0 / 225SP
V24	24 V dc
V12	12 V dc
GND	ground
FC-	-55 V or -70 V dual alternating
FC+	+55 V or +70 V dual alternating
CHS	110 Vac safety chain
TS1-A	← transformer, terminal block
L1.380	Entry 400V mains GRID (400V TRI)
T380	Entry 400V from transfo
T220	Output 230V from transfo
L1.220	Entry 230V mains EDF (230V MONO)
220F	Output 230V from transfo
220F	Output 230V from transfo
T0	Output 0V from transfo
L2	Entry 400V mains EDF (400V TRI)
L3.220	Entry 230V mains EDF (230V MONO)
L3.380	Entry 400V mains EDF (400V TRI)


TS2-A	← transformer
22	Output 22V from transfo
022	Output 0V from transfo
0110	Output 0V from transfo
110	Output 110V from transfo
55	Output 55V from transfo
70	Output 70V from transfo
CF1-A	(configuration brake voltage)
C55	Configuration FC+ / FC- in 55V
CFC	Common Configuration FC+ /FC-
C70	Configuration FC+ / FC- in 70V
AR1-A	← battery, load configuration
BAT-	Battery supply -
BAT+	Battery supply +
CFG 24V	Config. battery charge in 24Vdc
CFG 24V	Config. battery charge in 24Vdc
AR2-A	→ contactors
GND	ground
FCT	Brake / cam timed
FC-	-55 V or -70 V dual alternating
FC+	+55 V or +70 V dual alternating
AR3-A	→ voltage outputs
GND	ground
V24	24 V dc
22V	Info 24V not safeguarded (max 5A)
CHS	110 Vac safety chain

5.1.4 220SP motor interface board




CN1-I Connector connecting the 220SP power board to the 225SP and 226SP expansion boards	CN2-I Connector connecting the 220SP to the 214SP power supply board
CN3-I Safety chain inputs: 48-230Vac or 24Vdc >PE >VER Locking >SHP Landing shunt >AU Emergency stop >CHS Safety chain power supply	CN4-I Connector connecting the 220SP power board to the 216SP board
CN5-I <VER Locking <CCT Common contactor <L Line	CN6-I <BOOST Brake boost control <VENT Fan control V24 <CHAUF Heating control
CN7-I < K_EGA Shaft lighting control > E_GA Shaft lighting detection Opto-isolated / 24 Vdc to 230 Vac PE	CN8-I <S1 ... S5 VF controls COM
CN9-I <CAM 2 Door 2 cam control <OUV 2 Door 2 opening control V24 24 V <FER 2 Door 2 closing control	CN10-I >E1 Opto-isolated / 12-24 Vdc >E2 Opto-isolated / 12-24 Vdc GND GND
CN11-I <CAM 1 Door 1 cam control <OUV 1 Door 1 opening control V24 24 V <FER 1 Door 1 closing control	CN12-I >ST Thermal probe GND
CN13-I >STH/CFR1 Oil thermal probe / Brake state GND GND >SPR/CFR2 Brake state	CN14-I >CC Contactors control GND

5.1.5 226SP Hydraulic expansion board



CN1-0	Connector connected to 220SP power board CNI-I connector	CN2-0	Connector connected to 214SP power supply board CN4-A connector and to 220SP board CN2-I connector
CN3-0	>RTS Valve return >ALS+ Valve power supply	CN4-0	>L Line input
CN5-0	Connector connected to the CN5-1 connector of 220SP power board	CN6-0	<GND Common emergency descent valve <SDS Emergency descent valve <RTS Valve return <SDPV Low speed descent valve <SDGV High speed descent valve <RTS Valve return <SMGV High speed ascent valve <SMPV Low speed ascent valve
CN7-0	<L Line output <ET Star contactor output <TRI Triangle contactor output <NIV Levelling contactor output <CCT Common contactor		

5.1.7 212SP safety chain distribution board



AR1 Connector connecting 212SP board 220SP boards (Safety chain taking information)	MC1 Connector connecting call operation to 212SP board (Safety chain)
MC2 Connector connecting speed limiter to 212SP board	TR1 Connector connecting the end stops (reduced stand-by option)
TR2 Connector connecting pit inspection (Pit inspection option)	MC3 Connector connecting emergency operation to 212SP board (command)
TR3 Connector connecting the shunts and landing lockings (door securities)	MC4 Connector connecting top, bottom control (reduced stand-by option)
TR4 Connector connecting shaft safety mechanisms (Stop pit, tightener pulley etc.....)	PE2 Connector linking trailing cable to 212SP to 210SP boards (levelling safety)
PE5 Connector connecting trailing cable to 212SP to 221SP boards (reduced stand-by + pit inspection)	PE3 Connector connecting the trailing cable to 212SP to 210SP boards (telephone line)
MC5 Connector connecting car light DTU entry to the 212SP board	PE4 Connector connecting the trailing cable to 212SP to 210SP boards (main safety chain)
MC6 Connector connecting telephone line entry to 212SP board	AR2 Connector connecting the 212SP board to the 216SP board (Call information + CAR CAN BUS)

LED	STATUS	INFORMATION
LCP	On	Continuous 230V power supply (Car lighting)

CB1 - BAB 1A		CB2 - decelerators	
<V24C	24 V controlled	<GND	ground
<GND	ground	>RH	Top decelerator
>C1 to C8	Car button 1 to 8	<GND	ground
<FM	Up arrow	>RB	Bottom decelerator
<FD	Down arrow	<GND	ground
>BPALAR	Alarm button	<PE	Equipotential protection
>ECL	Emergency lighting	CB3 - Reader	
>FAC1	Accelerated closing service 1	<V12	12 V
>OAC1	Accelerated opening service 1	>D	Reader fault
>HP1C	Car loud speaker	<GND	ground
<AF	Display	>A	Reader input A
<GND	ground	<GND	masse
<PE	Equipotential protection	>B	Reader input B
CB4 – load weighing gauge		<GND	ground
<V24C	24 V controlled	>C	Reader input C
<V24C	24 V controlled	>Y11	ILS1 input for levelling
<GND	ground	>Y12	ILS1 input for levelling
<GND	ground	>Y21	ILS2 input for levelling
>CAP1	Input gauge 1	>Y22	ILS2 input for levelling
>CAP2	Input gauge 2	CB5 – inspection	
<V24C	24 V controlled	<V24C	24 V controlled
<V24C	24 V controlled	<GND	ground
<GND	ground	>BFER1	Closing button service 1
<GND	ground	>BOUV1	Opening button service 1
>CAP3	Input gauge 3	>INS	Inspection button
>CAP4	Input gauge 4	>LUG	Shaft light button
		>MI	Inspection up
		>DI	Inspection down
		>BTELI	Telephone button
		>BTELI	Telephone button

CB6 – telephone	<p><V12 12V <GND ground <V12 12V <GND ground <BTELI Telephone button <BTELI Telephone button < DIS Discriminator (dry contact) < DIS Discriminator <V24 24 V <PE Equipotential protection</p>	CB7 – load weighing	<p><V24C 24 V controlled <GND ground >SU Overload <GND earth >NSC Non stop full <GND ground >PR Presence <GND ground >INH Inhibiting load weighing <V24C 24 V controlled >VISU1 Analogue overload display >VISU2 Analogue overload display</p>
CB8 – Door 1 operator	<p><HP1P Landing loud speaker <V24C 24 V controlled <GND ground <GND ground <CHC1 Shock <COM Common outputs opto-coupled doors >CPC1 Cell safety >NUD1 Opto-coupled control of forced door closing >FCF1 Closing end limit <FER1 Opto-coupled control of door closing >FCO1 Opening end limit <OUV1 Opto-coupled control of door opening</p>	CB9 – BAB 1B	<p><V24C 24 V controlled <GND Earth >C9 à C12 Car button 9 to 12 VALJ Yellow remote alarm indicator light VALV Green remote alarm indicator light >BTELI Telephone button >BTELI Telephone button <FMP Arrow next departure up <FDP Arrow next departure down <V12 12V CCC Car priority key <VISU Output overload indicator light <VNESC Output non stop full indicator light <VISU1 Overload analogue display <DFT Output out of order indicator light <VISU2 Overload analogue display <PE Equipotential protection</p>
CB10 – Safety relay	<p><V24C 24 V controlled <GND Earth <Y11 ILS1 input to safety relay <Y12 ILS1 input to safety relay <Y21 ILS2 input to safety relay <Y22 ILS2 input to safety relay <VISO Levelling request <VISO Levelling request >IRS Safety relay status <GND Earth</p>	CN1 – connection 210SP	Connector connecting the 211SP board to the 210SP board
PE1 – CANBUS machinery	<p>>V24 Input 24 V >GND ground >V12 Input 12V BLI CANBUS shielding (reserved) (reserved) >CAN0_H Input CANBUS 0 HIGH >CAN0_L Input CANBUS 0 LOW</p>	CN6 – connection 223SP	Connector connecting the 211SP board to the 223SP boards
		CB12 –RS485 expansion	<p><V24C 24 V controlled <GND ground <RS485_H Output RS485 <RS485_L Output RS485 <V24C 24 V controlled <GND ground</p>

CB11 – CANBUS / RS485 expansion		CB13 – CANBUS output	
<V24	24 V	<V24C	24 V controlled
<GND	ground	<GND	ground
(reserved)		<GND	ground
(reserved)		>BLI	Shielding
<SCD_SUIV	Next control	<CAN1_H	CANBUS 1 HIGH
>BLI	Shielding	<CAN1_L	CANBUS 1 LOW
<RS485_H	Output RS485		
<RS485_L	Output RS485		
<CAN0_H	CANBUS 0 HIGH		
<CAN0_L	CANBUS 0 LOW		
CB14 – Power supplies			
<V24	24 V		
<GND	ground		
<V24	24 V		
<GND	Earth		
<V12	12 V		
<GND	ground		


LED	INFORMATION
CHC1	Shock Input
CPC1	Cell output
DIS	Discriminator output
INS	Inspection input
ISHC	
IDHCS_AV	
RH	Top decelerator
RB	Bottom decelerator
A	Reader A input
B	Reader B input
C	Reader C input
ETAT	CANBUS status
V12	12 V present
V24	24 V present
V24C	24 V controlled present

AR1 Earths connection (PE)	CB2 Connection of automatic car light 230V (managed by timer)
CB3 Connection of continuous car light 230V	CB4 Connection of automatic car light 230V (managed by timer)
CB5 Connection of continuous car light 230V	CB6 Connection of top inspection end limit
CB7 Connection of bottom inspection end limit	CB8 Connection of top and bottom inspection end limit
CB9 Connection of folded out balustrade	CB10 Connection of safety gear
CB11 Connection of inspection box (Inspection safety + plug car roof)	CB12 Connection of folded up balustrade
CB13 Connection of automatic or manual toe-guard	CB14 Connection of inspection box (Inspection safety)
CB15 Connection of rocker detection 1 m for automatic toe-guard + contact toe-guard status	CB16 Cell connection by 24Vdc or 230Vac (DOOR2)
CB17 Connection of 2 nd service stop	CB18 Connection of car trap-door
CB19 Cell connection by 24Vdc or 230Vac (DOOR1)	CB20 Connection door 1 motor power supply + door safety
CB21 Additional 230V power supply (Power supply provided by transfo in control panel)	CB22 Connection of safety relay (levelling door open)
CB23 Connection telephone line on telephone	CB24 Connection cam 1 (power supply configurable in control panel)

PE2 Connector connecting trailing cable to 210SP to 212SP boards (Levelling safety)	PE3 Connector connecting trailing cable to 210SP to 212SP boards (telephone line)
PE4 Connector connecting trailing cable to 210SP to 212SP boards (main safety chain)	PE6 Connector connecting trailing cable to terminals in control panel (Power supply 220F + Power supply motor)
PE7 Connector connecting trailing cable to terminals in control panel (Power supply cam 1)	CN1 Connector connecting 210SP board to the 221SP board (reduced stand-by + pit inspection option)
CN2 Connector connecting 211SP board to 210SP board	CN3 Connector connecting 210SP board to the 221SP board (reduced stand-by + pit inspection option)
CN4 Connector connecting 210SP board to 222SP board (Option 2 nd door service)	


LED	STATUS	INFORMATION
LCP	On	Continuous 230V power supply (Car lighting)

5.2.3 222SP power board for door second service




CN4
Connector connecting 222SP board to 210SP board (Option door 2 nd service)
PE9
Connector connecting the trailing cable to terminals in the control panel (Power supply motor brake injection door 1 & 2)
CB31
Connection power supply motor door 2 + door safety
PE10
Connector connecting the trailing cable to terminals in the control panel (Power supply motor door 2 + power supply cam 2)
CB30
Connection cam 2 (power supply configurable in control panel)
CB29
Connection motor brake injection door 2
CB28
Connection motor brake injection door 1

5.2.4 223SP extension board for door second service



<p>CB32 inspection</p> <p><V24C 24 V controlled <GND ground >BFER2 Closing button door 2 >BOUV2 Opening button door 2 <PE Equipotential protection</p>	<p>CB34 BAB 2B</p> <p><V24C 24 V controlled <GND ground >C9 à C12 Car button 9 to 12 (not used) (not used) ((not used) (not used) <FMP Next up departure arrow <FDP Next down departure arrow <V12 12V CCC Car priority key <VSU Overload light indicator output (not used) (not used) (not used) <PE Equipotential protection</p>
<p>CB35 Power supply</p> <p>>V12 Input 12 V <GND ground</p>	
<p>CB36 Door 2 operator</p> <p><HP2P Landing loud speaker <V24C 24 V controlled <GND ground <GND ground <CHC2 Shock <COM Common outputs opto-coupled doors >CPC2 Cell safety >NUD2 Opto-coupled control for forced door closing >FCF2 Closing end limit <FER2 Opto-coupled control for door closing >FCO2 Opening end limit <OUV2 Opto-coupled control for door opening</p>	<p>CB33 BAB 2A</p> <p><V24C 24 V controlled <GND earth >C1 à C8 Car button 1 to 8 <FM Up arrow <FD Down arrow (not used) >ECL Emergency lighting >FAC2 Accelerated closing service 2 >OAC2 Accelerated opening service 2 >HP2C Car loud speaker <AF Display <GND ground <PE Equipotential protection</p>
<p>CN1</p> <p>Connector connecting 211SP board to 223SP boards</p>	
<p>CN3</p> <p>Connector connecting the 223SP board to another 223SP board</p>	


5.2.5 230SP Bluetooth board



CN1 BUS CAN input		CN3 RS485	
>1	24 V	>1	V24
>2	CANH	>2	A
>3	CANL	>3	B
>4	GND	>4	GND
CN2 input LED telealarm			
>V	input green LED		
>CO	common		
>J	input yellow LED		


5.3 Landing electronics boards

5.3.1 228SP landing board



CN1 CANBus input	CN5 Display
>1 24 V DC	<1 24 VDC
>2 CANBUS 0 HIGH	>2 S3
>3 CANBUS 0 LOW	>3 S2
>4 GND	>4 S1/E1
CN3 RS485	<5 GND
<1 24 V DC	CN6 CANBus output
>2 485H	<1 24 V
>3 485L	<2 CANBUS 0 HIGH
<4 GND	<3 CANBUS 0 LOW
CN4 landing button 1	<4 GND
<1 24V DC	CN7 landing button 2
<2 BP1	<1 24V DC
>3 LED	<2 BP2
<4 GND	>3 LED
	<4 GND

5.3.2 137SP landing board with voice synthesizer



CN1 CANBus input		CN5 Display	
>1	24 V DC	<1	24 V DC
>2	CANBUS 0 HIGH	>2	S3
>3	CANBUS 0 LOW	>3	S2
>4	GND	>4	S1
CN3 RS485		<5	GND
<1	24 V DC	CN6 CANBus output	
>2	485H	<1	24 V
>3	485L	<2	CANBUS 0 HIGH
4	GND	<3	CANBUS 0 LOW
CN4 landing button 1		<4	GND
<1	24V DC	CN7 landing button 2	
<2	BP1	<1	24V DC
>3	LED	<2	BP2
<4	GND	>3	LED
		<4	GND

CN8 Landing door		CN11 Speaker	
<24 V	24 V DC	GND	HP
<SINH	Blocking door	<HP	HP
>EPOR	Landing door state		
<GND	GND		
CN9 Door alarm			
<24 V	24 V		
<SSIR	Alarm output		
>EARM	rearmament		
<GND	GND		

